## 3RA2220-1HF24-0AP0

**Data sheet** 



Load feeder fuseless, Reversing duty 400 V AC, Size S0 5.50...8.00 A 230 V AC Spring-type terminal for installation on standard mounting rail with standard mounting rail adapter (also fulfills type of coordination 1) Type of coordination 2, lq = 150 kA 1 NO+1 NC (contactor)

product brand name	SIRIUS
product designation	Reversing starter
design of the product	for standard rail or screw mounting
product type designation	3RA22
manufacturer's article number	
<ul> <li>of the supplied contactor</li> </ul>	3RT2024-2AP00
<ul> <li>of the supplied circuit-breakers</li> </ul>	3RV2021-1HA20
<ul> <li>of the supplied RH assembly kit</li> </ul>	3RA2923-1BB2
<ul> <li>of the supplied link module</li> </ul>	3RA2921-2AA00
General technical data	
size of the circuit-breaker	S0
size of load feeder	S0
insulation voltage with degree of pollution 3 at AC rated value	690 V
surge voltage resistance rated value	6 kV
degree of protection NEMA rating	other
shock resistance according to IEC 60068-2-27	6g / 11 ms
mechanical service life (switching cycles) of contactor typical	10 000 000
type of assignment	2
type of protection according to ATEX directive 2014/34/EU	Ex II (2) GD
certificate of suitability according to ATEX directive 2014/34/EU	DMT 02 ATEX F 001
Substance Prohibitance (Date)	03/01/2017
Ambient conditions	
ambient temperature	
<ul> <li>during operation</li> </ul>	-20 +60 °C
during storage	-50 +80 °C
during transport	-50 +80 °C
temperature compensation	-20 +60 °C
relative humidity during operation	10 95 %
Main circuit	
number of poles for main current circuit	3
design of the switching contact	electromechanical
adjustable current response value current of the current-dependent overload release	5.5 8 A
operating voltage	
rated value	690 V
<ul> <li>at AC-3 rated value maximum</li> </ul>	

operating frequency rated value	50 60 Hz
operational current at AC-3 at 400 V rated value	6.5 A
operating power at AC-3	
at 400 V rated value	3 000 W
Control circuit/ Control	
type of voltage of the control supply voltage	AC
control supply voltage at AC	
<ul> <li>at 50 Hz rated value</li> </ul>	230 V
at 50 Hz rated value	230 230 V
apparent holding power of magnet coil at AC	8.5 VA
Auxiliary circuit	
product extension auxiliary switch	Yes
Protective and monitoring functions	
trip class	CLASS 10
design of the overload release	thermal (bimetallic)
UL/CSA ratings	
full-load current (FLA) for 3-phase AC motor	
at 480 V rated value	8 A
yielded mechanical performance [hp]	
• for 3-phase AC motor	
— at 220/230 V rated value	2 hp
— at 460/480 V rated value	5 hp
— at 400/400 V rated value	5 hp
	3 lip
Short-circuit protection	V.
product function short circuit protection	Yes
design of the short-circuit trip	magnetic
conditional short-circuit current (Iq)	450,000 4
at 400 V according to IEC 60947-4-1 rated value	150 000 A
Installation/ mounting/ dimensions	
mounting position	vertical
mounting position fastening method	vertical  On adapter for screw and snap-on mounting on 35 mm standard mounting rail
	On adapter for screw and snap-on mounting on 35 mm standard
fastening method height width	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm
fastening method height	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm
fastening method height width	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm
fastening method height width depth	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm
fastening method height width depth required spacing	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm
fastening method  height width depth required spacing • for grounded parts	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm
fastening method  height width depth required spacing • for grounded parts — forwards	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm
fastening method  height width depth required spacing  • for grounded parts — forwards — backwards	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm
fastening method  height width depth required spacing  • for grounded parts — forwards — backwards — upwards	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 50 mm
fastening method  height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 50 mm
fastening method  height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 50 mm
fastening method  height width depth  required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 50 mm 10 mm
fastening method  height width depth required spacing  • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 50 mm 10 mm 10 mm
fastening method  height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 10 mm 10 mm 10 mm
fastening method  height width depth  required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — forwards  — backwards  — upwards  — upwards	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 10 mm 10 mm 10 mm 50 mm
fastening method  height width depth  required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — forwards  — backwards  — upwards  - downwards  — downwards  — downwards  — backwards  — backwards  — upwards  — downwards	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 10 mm 10 mm 10 mm 50 mm 10 mm
fastening method  height width depth  required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — backwards  — backwards  - at the side  — downwards  - at the side  — downwards  — forwards  — backwards  — backwards  — upwards  — downwards  — at the side	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 10 mm 10 mm 10 mm 50 mm 10 mm
fastening method  height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — at the side — downwards — to rewards — backwards — backwards — backwards — upwards — at the side  Connections/ Terminals	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 10 mm 10 mm 10 mm 50 mm 10 mm
fastening method  height width depth  required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — forwards  — backwards  — upwards  — at the side  Connections/ Terminals  type of electrical connection	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 10 mm 10 mm 50 mm 10 mm 10 mm 10 mm 10 mm 10 mm
fastening method  height width depth  required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — forwards  — backwards  — backwards  — upwards  — torwards  — backwards  — upwards  — at the side  Connections/ Terminals  type of electrical connection  • for auxiliary and control circuit	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 50 mm 10 mm 10 mm 50 mm 10 mm 50 mm 50 mm 50 mm
fastening method  height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards — upwards — backwards — upwards — at the side Connections/ Terminals  type of electrical connection • for main current circuit • for auxiliary and control circuit Safety related data	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 50 mm 10 mm 10 mm 10 mm 50 mm 50 mm 50 mm 50 mm
fastening method  height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — backwards — upwards — townwards — at the side  Connections/ Terminals  type of electrical connection • for main current circuit • for auxiliary and control circuit  Safety related data  B10 value with high demand rate according to SN 31920	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 50 mm 10 mm 10 mm 50 mm 10 mm 50 mm 50 mm 50 mm
fastening method  height width depth  required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — forwards  — backwards  — upwards  — backwards  — upwards  — downwards  — at the side  Connections/ Terminals  type of electrical connection  • for main current circuit  • for auxiliary and control circuit  Safety related data  B10 value with high demand rate according to SN 31920  proportion of dangerous failures	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 10 mm
fastening method  height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — backwards — upwards — the side  Connections/ Terminals  type of electrical connection • for main current circuit • for auxiliary and control circuit  Safety related data  B10 value with high demand rate according to SN 31920  proportion of dangerous failures • with high demand rate according to SN 31920	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 50 mm 10 mm 10 mm 10 mm 50 mm 10 mm 50 mm 10 mm 10 mm 10 mm 10 mm
fastening method  height  width  depth  required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — forwards  — backwards  — upwards  — backwards  — upwards  — the side  Connections/ Terminals  type of electrical connection  • for main current circuit  • for auxiliary and control circuit  Safety related data  B10 value with high demand rate according to SN 31920  proportion of dangerous failures  • with high demand rate according to IEC 60529	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 10 mm
fastening method  height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — backwards — upwards — the side  Connections/ Terminals  type of electrical connection • for main current circuit • for auxiliary and control circuit  Safety related data  B10 value with high demand rate according to SN 31920  proportion of dangerous failures • with high demand rate according to SN 31920	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 269 mm 90 mm 130 mm  32 mm 0 mm 50 mm 10 mm 10 mm 10 mm 50 mm 10 mm 50 mm 10 mm 10 mm 10 mm 10 mm

<ul> <li>PROFINET IO protocol</li> </ul>	No
PROFIsafe protocol	No
protocol is supported AS-Interface protocol	No

Certificates/ approvals

**General Product Approval** 

For use in hazardous locations

**Declaration of** Conformity



Confirmation







**Declaration of** Conformity

**Test Certificates** 

Marine / Shipping



**Special Test Certific-**<u>ate</u>

Type Test Certificates/Test Report







Marine / Shipping

other Railway









Confirmation

Vibration and Shock

Information- and Downloadcenter (Catalogs, Brochures,...)

https://www.siemens.com/ic10

Industry Mall (Online ordering system)

https://mall.industry.siemens.com/mall/en/en/Catalog/product?mlfb=3RA2220-1HF24-0AP0

Cax online generator

http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en&mlfb=3RA2220-1HF24-0AP0

Service&Support (Manuals, Certificates, Characteristics, FAQs,...)

https://support.industry.siemens.com/cs/ww/en/ps/3RA2220-1HF24-0AP0

Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros, ...)

http://www.automation.siemens.com/bilddb/cax\_de.aspx?mlfb=3RA2220-1HF24-0AP0&lang=en

Characteristic: Tripping characteristics, I2t, Let-through current

https://support.industry.siemens.com/cs/ww/en/ps/3RA2220-1HF24-0AP0/char

Further characteristics (e.g. electrical endurance, switching frequency)

http://www.automation.siemens.com/bilddb/index.aspx?view=Search&mlfb=3RA2220-1HF24-0AP0&objecttype=14&gridview=view1

last modified:

2/16/2022

