FWM-S1210MBD-S **SHOCK ABSORBER - ADJUSTABLE**

Bansbach easylift

or lower

44



SPECIFICATIONS								
Model		Stroke mm	Max Energy Absorption J(kgf⋅m)	Max Equiv. Rai Mass Impa kg(kgf) r		Rate		
FWM-S1210MBD-S		10	4.9(0.5)	30(30)	0.3~2		Multiple- varying orifice type	
COMMON SPECIFICATIONS								
Max Drag N(kgf)	R	Cycle ate e/min	Max Energy Absorption per n J/min(kgf∙m/m	nin. F	ension orce (kgf)	Operating Temp. C°		Mass g
1470(150)		50	98(10)	9.8	8(1.0)	-5	~70	44

PRECAUTIONS FOR USE

98(10)

60

- Do not use this product in places where it may come in contact with oil as it does not have a liquid-proof structure.
- Please contact our sales department when the use of optional parts is planned.


1470(150)

Although the dimensions are identical to those of the FA series standard products (adjustable), the FWM-S2016 series has a longer overall length.

ADJUSTMENT METHOD

- Please peruse the operation manual carefully before use.
- Do not operate without sufficient mounting strength.
- Do not operate without an external stopper.
- Note that Products specification might be changed without notice.


ABSORPTION CHARACTERISTICS





OPTIONAL PARTS

Eccentric angle adaptor OP-010KB

- Screw the eccentric angle adaptor into the main unit until the cap for the eccentric angle and the piston rod form a tight connection. While maintaining this position, fasten the main unit's nut until it is secured.
- Use the eccentric angle adaptor when the eccentric angle is 2.5° or larger.
- The main unit can also be used as a stopper.
- Use it with a capless soft absorber.
- The maximum operating eccentric angle with an eccentric angle adaptor is ±10°.
- The caps and the guides for inclined use are not unbundled.








Stopper nut OP-020KB

 Adjust so that it stops 1 mm before the stroke end, and fasten with the main unit's nut until secured.




Mass 8g

Note: When attaching, make sure that the side without a bearing chamfer is the impact surface.

Standard nuts are sold separately as well - M12 Nut

Square flange OP-040KB


 Once the attachment site is determined, use the main unit's nut to securely fasten in place.



Mass 16g

Liquid-proof cap FWM-1210MBD-C-060

- Ideal for use in environments where oil splatter poses a problem.
- Ensure that the cap is facing upward. If the cap is facing sideways or downward, it cannot provide an effective means for liquid proofing.



Holder with a switch OP-030KB-2

Although a holder with a switch can be ordered on its own, we strongly recommend ordering one with the main unit. Please include the main unit's model number when placing an order.

