



Detailed installation procedure

1a. Place Nut, Body, and Gland seal onto the cable.

1b. Insert LC connectors and latch into place.

2. Push ^{NOTE 1} and Slide Body forward and lock in place, the marking features are aligned.

3a. Slide the gland seal into the rear of the body.

3b. Slide Nut forward to the body as shown, turn the NUT till it is stopped by body ^{NOTE 2}.

NOTE:

1. Make sure the slot in the body mated in the rib in the bulkhead, Push the body till to the end, then Lock in place.
2. Turn the nut without tool, can be operated by hand.
3. Failure to follow these instructions and recommendations may result in reduction of cable retention and environmental sealing performance, possibly leading to service interruption. Please see detailed cable assembly requirements on TE drawing.