


UM1918 User manual

Getting started with the X-NUCLEO-PLC01A1 industrial input/output expansion board for STM32 Nucleo

Introduction

The X-NUCLEO-PLC01A1 is an expansion board designed to build basic PLC (programmable logic controller) applications. Plugged onto any STM32 Nucleo board through the Arduino UNO R3 connectors, it results in a compact industrial PLC capable of managing eight analog inputs and eight outputs through the SPI peripheral. The 24 V power supply makes it possible to manage industrial range inputs (i.e. sensors, valves) and outputs (i.e. lamps, alarms). The board is not intended to utilize all of the features of the CLT01-38SQ7 and the VNI8200XP devices. The X-NUCLEO-PLC01A1 embeds diagnostics and fault LEDs, as well as activity status LEDs for all channels in input and output. Compatibility with the STM32 Nucleo family of boards as well with other expansion boards is assured by the use of Arduino UNO R3 connectors, while the board schematics, bill of materials, Gerber files, drivers and firmware are available for download on www.st.com.



July 2015 DocID028079 Rev 1 1/16

Contents UM1918

Contents

1	Description	3
2	Features	4
3	Hardware and layout description	5
4	X-NUCLEO-PLC01A1 assembly drawing	6
5	X-NUCLEO-PLC01A1 board powering and startup	7
6	Schematic diagrams	8
7	Bill of material	12
8	Revision history	15

UM1918 Description

1 Description

To perform industrial IO (input/output) management, the X-NUCLEO-PLC01A1 is equipped with CLT01-38SQ7 and VNI8200XP ICs. Both devices on the board work through the SPI peripheral, and as such any STM32 Nucleo board to which it is connected can implement an industrial PLC application. Both devices support 8- and 16-bit SPI interfaces for device command and control diagnostics. The board is equipped with a digital isolator in order to assure SPI safe operation between the X-NUCLEO-PLC01A1 and the STM32 Nucleo board. The VNI8200XP includes advanced protection and fault detection features. CLT01-38SQ7 provides protection and isolation in industrial operating conditions as well as an "energy-less" status indication for each of the eight input channels, with minimal power consumption. It is suited for situations that require test standards IEC61000-4-2 8 kV and 15 kV to be met. Both the CLT01-38SQ7 and the VNI8200XP are designed to meet the most common industrial requirements (i.e. IEC61000-4-2, IEC61000-4-4, IEC61000-4-5 or IEC61131-2). For more thorough evaluation of the individual products, it is recommended to refer to their single respective evaluation boards, available on st.com.



Features UM1918

2 Features

The X-NUCLEO-PLC01A1 is a ready-to-use PCB (printed circuit board) including:

- 8x input with CLT01-38SQ7, high-speed protected digital termination array
- 8x output with VNI8200XP, high-side solid state relay
- Status LEDs: Fault, Thermal, Power
- IO (input/output) activity LEDs
- 24 V power supply
- Compatible with Arduino UNO R3 connector

A reverse polarity diode is part of the input stage. As a result, when a 24 V supply is applied to the input connector, the supply voltage on the CLT01-38SQ7 device is given by: $V_{\text{supply}} - V_{\text{FWD}}$, where V_{FWD} is the voltage applied on the reverse diode.

Capacitors C15 and C19 are not mounted. They are only needed to perform common mode surge tests.

3 Hardware and layout description

The X-NUCLEO-PLC01A1 board adds to any STM32 Nucleo board the capabilities of a compact industrial PLC with 8 inputs and 8 outputs. This is possible through SPI management as depicted in the functional block diagram below.

Ext. High (24V) voltage supply

Inputs:
Industrial sensors
Valves

The series of the s

Figure 2: Functional block diagram

4 X-NUCLEO-PLC01A1 assembly drawing

The main components of the board are specified in the drawing below. The X-NUCLEO-PLC01A1 is shaped in such a way as to allow easy access to the STM32-Nucleo board when both boards are connected. Input and output channels are accessible through the screw connectors placed on the low side of the X-NUCLEO-PLC01A1 (connectors J8 and J10, respectively), and each channel is associated to one LED in order to indicate its activity and status. Another three LEDs are provided on the board to provide status and diagnostic information for the VNI8200XP device (temperature warning, fault and Power Good detection). The SPI selector allows the CLT01-38SQ7 device to be managed in 8-bit or 16-bit bus mode.




Figure 3: Top assembly view

5 X-NUCLEO-PLC01A1 board powering and startup

The following steps must be followed to run the X-NUCLEO-PLC01A1:

- 1. Plug the X-NUCLEO-PLC01A1 onto a STM32 Nucleo board
- 2. Connect the STM32 Nucleo board to a PC via a standard Type A / mini B USB cable
- Download the firmware on the STM32 microcontroller hosted on the STM32 Nucleo board
- 4. Supply 24 V to the X-NUCLEO-PLC01A1 board through the J8 connector
- 5. The X-CUBE-PLC1 demonstration firmware is ready to run: connect any of the 8 inputs on the J8 connector to see the corresponding output on the J10 connector capable of driving a load (i.e. short-circuit input "x" with the 24 V and connect the corresponding output "x" to a load).



Schematic diagrams UM1918

6 Schematic diagrams

Morpho Connectors CN7 CN10 100nF Morpho_Connector Morpho Connector **Nucleo Connectors** HEADER 10 CN9 SPI_SCK HEADER 8 Note :-- All Resistors in this section should be SMD080 5 SPI activity LEDs SPI Activity LED R15 330R SPI_SCK DNM DNM

Figure 4: X-NUCLEO-PLC01A1 schematic, part 1

UM1918 Schematic diagrams

Figure 5: X-NUCLEO-PLC01A1 schematic, part 2 CLT01-38SQ7 Input

Schematic diagrams UM1918






Figure 6: X-NUCLEO-PLC01A1 schematic, part 3

UM1918 Schematic diagrams

Figure 7: X-NUCLEO-PLC01A1 schematic, part 4





Bill of material UM1918

7 Bill of material

Table 1: Bill of material (BOM)

Qt y.	Designator	Value	Part number	Comme nt	Package ref.
4	C9, C23, C24, C27	100 nF	C1005X7R1H104K050 BB		SMD 0402
9	C3, C13, C14, C20, C25, C26, C40, C44, C45	33 pF	C1005C0G1H330J050 BA		SMD 0402
17	C4,C5,C6,C7,C8,C10,C1 1,C12, C29, C30, C31, C32, C34, C35, C36, C37,C28	22 nF	C1608X7R1H223K080 AA		SMD 0603
2	C15, C19	4.7 nF	VY1472M63Y5UQ63V 0	Not mounte d	Through Hole 10 mm lead spacing
2	C16, C21	1 µF	C1608X5R1H105K080 AB		SMD 0603
1	C17	100 μF	EEE-FTH101XAP		SMD
1	C18	33 nF	C1608X7R1H333K080 AA		SMD 0603
1	C22	10 μF	T491A106M006AT		SMD 1206
2	C38, C39	10 nF	C1005X7R1H103K050 BB		SMD 0402
1	C33	10 nF	C1608X7R1H103K080 AA		SMD 0603
1	C41	470 nF	C1608X5R1A474K080 AA		SMD 0603
1	C42	4.7 μF	CGB3B1X5R1A475K0 55AC		SMD 0603
1	C43	100 pF	C1608C0G1H101J080 AA		SMD 0603
3	C46, C47, C48	100 pF	C1005C0G1H101F050 BA		SMD040 2
2	C1, C2	100 nF	C2012X7R1H104K085 AA		SMD 0805
2	CN7, CN10	Morpho connectors	SSQ-119-04-L-D		Through hole 2.54 mm
1	CN5	Header_10	SSQ-110-03-L-S	Mount female type on top, male type on bottom	Through hole 2.54 mm

UM1918 Bill of material

Ot				Commo	Dackass
Qt y.	Designator	Value	Part number	Comme nt	Package ref.
2	CN6, CN9	Header_8	SSQ-108-03-L-S	Mount female type on top, male type on bottom	Through hole 2.54 mm
1	CN8	Header_6	SSQ-106-03-L-S	Mount female type on top, male type on bottom	Through hole 2.54 mm
3	D24, D23, D22	LED	LS L29K-G1J2-1-Z	Red color	SMD 0603
17	D2, D11, D12, D13, D14, D15, D16, D17, D18, D25, D26, D27, D28, D29, D30, D31, D32	LED	LG L29K-G2J1-24-Z	Green color	SMD 0603
1	D21	BAT48	BAT48ZFILM		SOD-123
1	D19	SM15T33CA	SM15T33CA		SMC_B
1	D20	STPS1H100A	STPS1H100A		SMA
1	J5	Jumper_2		Female type jumper to be mounte d	Through hole 2.54 mm
1	J8	INPUT_connect or	1725711		Through hole 2.54 mm
1	J10	OUTPUT_conne ctor	1725737		Through hole 2.54 mm
1	J11	Jumper_3		Female type jumper to be mounte d	Through hole 2.54 mm pitch
1	L1	100 μH	SRN4018-101M		SMD
1	R15	330 Ω	ERJ-2GEJ331X		SMD 0204
2	R28, R38	0 Ω	ERJ-2GE0R00X		SMD 0204
11	R58, R59, R60, R61, R62, R63, R64, R65, R66, R67, R68	680 Ω	ERJ-2GEJ681X		SMD 0204

Bill of material UM1918

Qt y.	Designator	Value	Part number	Comme nt	Package ref.
2	R25, R49	47 kΩ	ERJ-2GEJ473X		SMD 0204
1	R26	15 kΩ	ERJ-2GEJ153X		SMD 0204
9	R27 ,R39, R41, R45, R50, R51, R52, R56, R57	220 Ω	ERJ-2GEJ221X		SMD 0204
9	R29, R30, R32, R33, R34, R35, R36, R37, R42	2.2 kΩ	MMA02040C2201FB3 00		SMD 0204
4	R40, R46, R47, R48	10 kΩ	ERJ-2GEJ103X		SMD 0402
1	R43	1.5 ΜΩ	MMA02040C1504FB3 00		SMD 0204
1	R44	120 kΩ	MMA02040C1203FB3 00		SMD 0204
1	R53	2 kΩ	ERJ-3EKF2001V		SMD 0603
1	R54	10 kΩ	ERJ-3GEYJ103V		SMD 0603
1	R55	3.3 kΩ	ERJ-3EKF3301V		SMD 0603
1	U3	Si Digital Isolator	SI8661BC-B-IS1		16 pin narrow body SOIC
1	U1	CLT01-38SQ7	CLT01-38SQ7		QFN
1	U2	VNI8200XP	VNI8200XP		PowerSS O-36
7	R1, R2, R3, R4, R5, R6, R13	0 Ω		Closed	
2	Jumper		969102-0000-DA		

UM1918 Revision history

8 Revision history

Table 2: Document revision history

Date	Version	Changes
17-Jul-2015	1	Initial release.

IMPORTANT NOTICE - PLEASE READ CAREFULLY

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2015 STMicroelectronics - All rights reserved

