



Quick Start Guide

XBee-PRO® XSC RF Modem



Welcome to your Digi product

Get started: This guide helps you with initial product setup. Need more? Find additional product support at www.digi.com/support/XBeePROXSC-Modem. Or connect to the online documentation by scanning this code:



Digi Technical Support: Digi offers multiple support plans to help you get the most out of your product. For information on Technical Support plans and pricing, contact us at 877.912.3444 or visit www.digi.com/support.


Documentation Feedback: To provide feedback on this documentation, send your comments to techcomm@digi.com.

1 Verify your components


Included equipment




XSC RF modem




**Phoenix connector
(RS-485 variant only)**




RPSMA antenna




**USB cable
(USB variant only)**



Power supply



**Mini USB cable
(RS-232 and RS-485 variants only)**



**DB9 cable
(RS-232 variant only)**

Verify that you have all included equipment. If any item is missing or damaged, contact your supplier.

2 Symbols on the RF modem



Not applicable to XSC RF modem



Reset button



RS-232 serial port

A·T·R

I/O LEDs
Red- Association
Green- Transmit from host
Yellow- Receive from host




Switch 1-Termination for 2-wire configuration
Switch 2-Termination for 4-wire configuration



Not applicable to XSC RF modem



Power supply (7-30 VDC)



RS-485 serial port



Antenna port



USB port

To get started with your kit, go to the Documentation tab at www.digi.com/support/XBeePROXSC-Modem.