



## PC362-3 Versa Power Cleaner Eraser Pad

Model # PC362-3

### Product Specifications

The Dremel Versa Eraser Pad gently removes dirt, stains and scuff marks from hard surfaces. Perfect for doors, walls, floors and more, the micro-abrasive surface can be used dry or with water. Combine the multi-purpose cleaning pad with the Dremel Versa's high speed scrubbing action, and jobs will be complete in no time.

- Multi-purpose micro-abrasive for use on hard surfaces
- Recommended uses: walls, floors, doors, shoes, glass and more
- Quick and easy accessory change with the hook and loop system
- Oversized accessories get into corners and tight spaces

<b>DIMENSIONS</b>	
Diameter:	2.5"
Weight:	0.11 [kg, lb, oz]
Application:	Indoor cleaning (counter tops, baseboards, appliances, walls,...); Outdoor cleaning (glass on your patio furniture, tiles, sneakers...)
Material:	Melamine Foam
RPM:	1900

[https://www.dremel.com/en\\_US/products/-/show-product/accessories/pc362-3-versa-power-cleaner-eraser-pad](https://www.dremel.com/en_US/products/-/show-product/accessories/pc362-3-versa-power-cleaner-eraser-pad) 10-11-18