LED..R70XD4-..High-Intensity Ring Light



Datasheet

High-Intensity LED Ring Light for use with PresencePLUS® and other Vision Systems




- Compact ring light for *Presence*PLUS® and other Vision Systems
 Four extremely bright LEDs for illumination of targets from 0.15 meters to beyond 2 meters (0.49 feet to 6.56 feet)
- Continuous or strobed operation
- Fixed or adjustable intensity, depending on model
- Maintenance-free, rugged construction
- Evenly and intensely illuminates a 610 millimeters (24 inches) diameter at 1 meter (3.28 feet)

Models

Model ¹	LED Color	Bracket	Cable	
LEDRR70XD4-XQ	Red, 625 nm			
LEDWR70XD4-XQ	White, 5500 K		150 mm (6 in) cable with threaded 5-pin Euro-style connector ²	
LEDBR70XD4-XQ	Blue, 470 nm	Optional bracket available (see Brackets)		
LEDGR70XD4-XQ	Green, 530 nm			
LEDIR70XD4-XQ	Infrared, 850 nm			
LEDRR70XD4-XM	Red, 625 nm			
LEDWR70XD4-XM	White, 5500 K		300 mm (12 in) cable with threaded 3-pin Pico- style connector 3	
LEDBR70XD4-XM	Blue, 470 nm	Built-in P4 bracket (see Dimensions)		
LEDGR70XD4-XM	Green, 530 nm			
LEDIR70XD4-XM	Infrared, 850 nm			

Wiring




Pinouts of the original 4-pin connector is the same as above, but without the center pin (gray wire).

Wire Purpose	Cable Wire Color 4	Continuous On Mode	Strobed Mode	PresencePlus Pro Controller Terminal Block
Power Wires	Power Wires Brown (1)		+24 V DC	Pin 01
	Blue (3)	common	common	Pin 02
Strobe Polarity Control Gray (5)	Orm (F)	open	Active Low: open	Pin 02
	Gray (5)		Active High: connect to common (Blue wire)	
Strobe Voltage Wires	White (2)	open	0 V DC = ON (Active Low) +5 V DC to 24 V DC = OFF (Active Low)	Pin 04
			0 V DC = OFF (Active High) +5 V DC to 24 V DC = ON (Active High)	FIII 04
	Black (4)	open	Strobe common	Pin 02

Note: To meet CE certification requirements, the light needs to be connected to earth ground.

Requires Euro-style cordset.
Connects directly to the P4 sensor.





Original Document 134757 Rev. G 27 May 2021

For models with controllable intensity, add " \mathbf{P} " to the model number (for example, **LEDRR70XD4-PQ**).

Light Intensity Adjustment

Turn the 270° intensity potentiometer with a small flat-blade screwdriver to adjust the light's intensity.

- 1. Apply power to the light and turn the potentiometer all the way clockwise for maximum intensity.
- 2. If the object to be sensed is too bright at maximum intensity, turn the potentiometer counterclockwise, a little at a time, testing with the target object, until the correct brightness is achieved.

Specifications

Light Source
Four high-intensity LEDs; see models table for wavelengths

Illumination

610 mm (24 in) diameter usable light pattern at 1 m (3.28 ft)

Strobe

Optically isolated

Supply Voltage and Current
Operating Voltage: 24 V DC ±10%
Strobe Voltage: 5 V DC to 24 V DC at 15 mA maximum
Current Draw at Full Intensity: 350 mA maximum
Built-in constant current regulator for LEDs
Potentiometer controls variable intensity for "P" models

Construction

onstruction

Enclosure rating: IP50

Housing: aluminum, black anodized

Window: acrylic, clear with frosted diffusing surface on the inside

Bracket: aluminum, black anodized. Attaches ring light directly to PresencePLUS

P4 with two included M4×14 screws

Useful Life


50,000 hours (LED ON time). When operated within specifications, output will decrease less than 30% after 50,000 hours

Operating Conditions

Temperature: 0 °C to +50 °C (+32 °F to +122 °F)
Humidity: 90% maximum relative humidity (non-condensing)

Dimensions

All measurements are listed in millimeters [inches], unless noted otherwise.



Accessories

Cordsets

5-Pin Threaded M12 Cordsets—Single Ended							
Model	Length	Style	Dimensions	Pinout (Female)			
MQDC20-506	2 m (6.56 ft)	Straight	42 Typ. [1.65"] M12 x 1 ø 15 [0.59"]	_ ^			
MQDC20-515	5 m (16.4 ft)			1 100			
MQDC20-530	9 m (29.5 ft)			1 = Brown 2 = White 3 = Blue 4 = Black 5 = Gray			

Accessory Brackets

SMBPPRHI

- Black zinc plated cold rolled steel
- Black zinc plated cold folled steel bracket
 Mounts directly to
 Presence PLUS Pro sensor
 Includes: 2 6-32 screws (socket
 drive, button head) 4 M3
 screws (socket drive, cap head)



Banner Engineering Corp. Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for one year following the date of shipment. Banner Engineering Corp. will repair or replace, free of charge, any product of its manufacture which, at the time it is returned to the factory, is found to have been defective during the warranty period. This warranty does not cover damage or liability for misuse, abuse, or the improper application or installation of the Banner product.

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXPRESS OR IMPLIED (INCLUDING, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORMANCE, COURSE OF DEALING OR TRADE USAGE.

This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering Corp., replacement. IN NO EVENT SHALL BANNER ENGINEERING CORP, BE LIABLE TO BUYER OR ANY OTHER PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSS OF PROFITS, OR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT OR WARRANTY, STATUTE, TORT, STRICT LIABILITY, NEGLIGENCE, OR OTHERWISE.

Banner Engineering Corp. reserves the right to change, modify or improve the design of the product without assuming any obligations or liabilities relating to any product previously manufactured by Banner Engineering Corp. Any misuse, abuse, or improper application or installation of this product or use of the product for personal protection applications when the product is identified as not intended for such purposes will void the product warranty. Any modifications to this product without prior express approval by Banner Engineering Corp will void the product warranties. All specifications published in this document are subject to change; Banner reserves the right to modify product specifications or update documentation at any time. Specifications and product information in English supersede that which is provided in any other language. For the most recent version of any documentation, refer to: www.bannerengineering.com.

For patent information, see www.bannerengineering.com/patents.

