
SMB22RAVK

- V-Clamp, right-angle bracket and fasteners for mounting to pipe or extensions Clamp accommodates 28 mm diameter tubing or 1 in. square extrusions 22 mm hole for mounting sensor



SMBAMS22P

- Flat SMBAMS series bracket with 22 mm hole for mounting sensors
 Articulation slots for 90+° rotation
- 12-ga. (2.6 mm) cold-rolled steel




Hole size: A = 0.22.5

Hole center spacing: A = 26.0, A to B = 13.0 Hole size: A = 26.8 x 7.0, B = Ø 6.5, C = Ø 22.5


SMBAMS22RA

- Right-angle SMBAMS series bracket with 22 mm hole for mounting sensors
 Articulation slots for 90+° rotation
- 12-ga. (2.6 mm) cold-rolled steel



TC-K30-CL

Touch cover



Diameter: A = 40.7 Height: B = 31

Hole center spacing: A = 26.0, A to B = 13.0 **Hole size:** $A = 26.8 \times 7.0$, $B = \emptyset 6.5$, $C = \emptyset 22.5$

All measurements are listed in millimeters, unless noted otherwise.

Banner Engineering Corp. Limited Warranty

Banner Engineering Corp. warrants its products to be free from defects in material and workmanship for carny product of its manufacture which, at the time it is returned to the factory, is found to have been defer improper application or installation of the Banner product. date of s Banner Engineering Corp. will repair or replace, free of charge, anty does not cover damage or liability for misuse, abuse, or the

THIS LIMITED WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES WHETHER EXFITNESS FOR A PARTICULAR PURPOSE), AND WHETHER ARISING UNDER COURSE OF PERFORM G, WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR STRADE USAGE.

BANNER ENGINEERING CORP. BE LIABLE TO BUYER OR ANY OTHER AL OR SPECIAL DAMAGES RESULTING FROM ANY PRODUCT DEFECT OR TRICT LIABILITY, NEGLIGENCE, OR OTHERWISE. This Warranty is exclusive and limited to repair or, at the discretion of Banner Engineering C PERSON OR ENTITY FOR ANY EXTRA COSTS, EXPENSES, LOSSES, LOSS OF PROFITS, FROM THE USE OR INABILITY TO USE THE PRODUCT, WHETHER ARISING IN CONTRACT VENT SH

without assumed and the product previously manufactured by Banner of the product protection applications when the product is identified as not intended for such two aby Banner angreering Corp will void the product warranties. All specifications published in this documentation at any time. Specifications and product information in English supersede that which is engineering.com. Banner Engineering Corp. reserves the right to change, modify or improve the design of Engineering Corp. Any misuse, abuse, or improper application or installation of this produpurposes will void the product warranty. Any modifications to this production are subject to change; Banner reserves the right to provided in any other language. For the most recent version or sufficient to the change of the change in the change is a contract to the change in the change is a contract to the change is a contract

For patent information, see www.bannerengineering.com

FCC Part 15 and CAN ICE (B)/NMB-3

This device complies with part 15 of the FCC Rules and CAN /NMB-3(B), Ope is subject to the following two conditions:

- This device may not cause harmful interference, an
- 2. This device must accept any interference received, inclunay cause undesired operation.

This equipment has been tested and found to comply with the limits for a reasonable protection against harmful interference in a residential installationstructions, may cause harmful interference to radio communications. Howe to radio or television reception, which can be determined by turning the equipment of the reception of al device, pursuant to part 15 of the FCC Rules and CAN ICES-3 (B)/NMB-3(B). These limits are designed to provide quipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the nere is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference and off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

 Increase the separation between the equipment and receiver.

 Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

 Consult the manufacturer.