

Introduction

The STM32L4R9I-EVAL board is designed as a complete demonstration and development platform for the STMicroelectronics Arm® Cortex®-M4 core-based STM32L4R9AI microcontroller with four I²C buses, three SPI and six USART ports, CAN port, two SAI ports, 12-bit ADC, 12-bit DAC, internal 640-Kbyte SRAM and 2-Mbyte Flash memory, two Octo-SPI memory interfaces, touch-sensing capability, USB OTG FS port, LCD-TFT controller, MIPI® DSI host controller, flexible memory controller (FMC), 8- to 14-bit camera interface and JTAG debugging support.

The STM32L4R9I-EVAL, shown in [Figure 3](#), [Figure 4](#), and [Figure 5](#), is used as a reference design for user application development before porting to the final product.

The full range of hardware features on the board helps the user to evaluate all the peripherals (USB, USART, digital microphones, ADC and DAC, TFT LCD, MIPI DSISM display, LDR, SRAM, NOR Flash memory device, Octo-SPI Flash memory device, microSD™ card, sigma-delta modulators, CAN transceiver, EEPROM) and develop applications. Extension headers allow easy connection of a daughterboard or wrapping board for a specific application.

An ST-LINK/V2-1 is integrated on the board, as the embedded in-circuit debugger and programmer for the STM32 MCU and the USB virtual COM port bridge.

Contents

- 1 Features 8**
- 2 Ordering information 9**
 - 2.1 Codification 9
- 3 Development environment 10**
 - 3.1 System requirements 10
 - 3.2 Development toolchains 10
 - 3.3 Demonstration software 10
- 4 Delivery recommendations 10**
- 5 Technology partners 10**
- 6 Hardware layout and configuration 11**
 - 6.1 STM32L4R9I-EVAL board views 13
 - 6.2 Mechanical dimensions 16
 - 6.3 ST-LINK/V2-1 17
 - 6.3.1 Drivers 18
 - 6.3.2 ST-LINK/V2-1 firmware upgrade 18
 - 6.4 ETM trace 18
 - 6.5 Power Supply 19
 - 6.5.1 Supplying the board through ST-LINK/V2-1 USB port 20
 - 6.5.2 Using ST-LINK/2-1 along with powering through the CN18 power jack 20
 - 6.6 Clock references 22
 - 6.7 Reset sources 23
 - 6.8 Boot option 23
 - 6.8.1 Bootloader limitations 24
 - 6.9 Audio 25
 - 6.9.1 Digital microphones 25
 - 6.9.2 Headphones outputs 26
 - 6.9.3 Limitations in using audio features 26
 - 6.10 USB OTG FS port 26

6.10.1	STM32L4R9I-EVAL used as a USB device	26
6.10.2	STM32L4R9I-EVAL used as a USB host	27
6.10.3	Limitations in using USB OTG FS port	27
6.10.4	Operating voltage	27
6.11	RS232 port	27
6.11.1	Operating voltage	27
6.12	microSD™ card	27
6.12.1	Limitations	27
6.12.2	Operating voltage	27
6.13	Motor control	28
6.13.1	Board modifications to enable motor control	30
6.13.2	Limitations	30
6.14	CAN	33
6.14.1	Limitations	33
6.14.2	Operating voltage	33
6.15	Extension connectors CN5, CN6, CN13, and CN14	34
6.16	User LEDs	34
6.17	Physical input devices	34
6.17.1	Limitations	35
6.18	Operational amplifier and comparator	35
6.18.1	Operational amplifier	35
6.18.2	Comparator	36
6.18.3	Limitations	37
6.19	Analog input, output, VREF	37
6.20	SRAM device	37
6.20.1	Limitations	38
6.20.2	Operating voltage	38
6.21	NOR Flash memory device	38
6.21.1	Limitations	38
6.21.2	Operating voltage	39
6.22	EEPROM	39
6.22.1	Operating voltage	39
6.23	EXT_I2C connector	39
6.24	Octo-SPI Flash memory device	39
6.24.1	Limitations	40

6.24.2	Operating voltage	40
6.25	Octo-SPI DRAM device	40
6.25.1	Operating voltage	40
6.25.2	Limitations	40
6.26	Touch-sensing button	40
6.26.1	Limitations	42
6.27	MFX MCU	42
6.28	IDD measurement	43
6.29	DSI display (MIPI) connector	43
6.29.1	Limitations	44
6.30	TFT LCD (RGB and FMC mode) connector	45
6.30.1	Limitations	46
6.31	PMOD connector	46
6.32	MB1314 DSI display board	46
6.33	MB1315 TFT LCD board	47
7	Connectors	49
7.1	CN1 motor-control connector	49
7.2	CN2 external I ² C connector	50
7.3	CN3 USB OTG FS Micro-AB connector	50
7.4	CN4 analog input-output connector	51
7.5	CN5, CN6, CN13, and CN14 extension connectors	51
7.6	CN7 RS232 connector	57
7.7	CN8 microSD™ connector	57
7.8	CN9 MFX programming connector	58
7.9	CN11 STDC14 connector	58
7.10	CN12 trace debugging connector	59
7.11	CN15 TAG connector	59
7.12	CN16 DSI display connector (MIPI)	60
7.13	CN17 JTAG connector	60
7.14	CN18 power connector	61
7.15	CN19 ST-LINK/V2-1 programming connector	61
7.16	CN20 TFT LCD connector (RGB)	61
7.17	CN21 ST-LINK/V2-1 USB Micro-B connector	61

7.18	CN22 CAN D-type male connector	62
Appendix A	I/O assignment	63
8	STM32L4R9I-EVAL board information	69
8.1	Product marking	69
8.2	Board revision history	70
8.3	Board known limitations	70
Revision history	71

List of tables

Table 1.	Ordering information	9
Table 2.	Codification explanation	9
Table 3.	Setting of configuration elements for CN12 trace connector	19
Table 4.	Power supply related jumpers settings	21
Table 5.	X1 crystal related solder bridge settings	22
Table 6.	X2 crystal related solder bridge settings	23
Table 7.	Boot selection switch	24
Table 8.	Digital microphone-related jumper settings	25
Table 9.	Motor-control terminal and function assignment	28
Table 10.	CAN related jumpers	33
Table 11.	Port assignment for control of physical input devices	35
Table 12.	Configuration elements related to OpAmp1	36
Table 13.	Configuration elements related to Comp2	36
Table 14.	SRAM chip select configuration	38
Table 15.	NOR Flash memory-related jumper	38
Table 16.	Configuration elements related to Octo-SPI Flash device	39
Table 17.	Touch-sensing-related configuration elements	41
Table 18.	MFX signals	42
Table 19.	IDD measurement related jumper setting	43
Table 20.	CN16 DSI display module connector	44
Table 21.	CN20 TFT LCD module connector	45
Table 22.	P1 PMOD connector	46
Table 23.	Pin function description of the CN1 MB1314 board connector	46
Table 24.	Pin function description of the CN1 MB1315 board connector	48
Table 25.	CN1 motor-control connector	49
Table 26.	CN2 EXT_I2C connector	50
Table 27.	CN3 USB OTG FS Micro-AB connector	50
Table 28.	CN4 analog input-output connector	51
Table 29.	CN5 daughterboard extension connector	51
Table 30.	CN6 daughterboard extension connector	52
Table 31.	CN13 daughterboard extension connector	54
Table 32.	CN14 daughterboard extension connector	55
Table 33.	RS232 D-sub male connector	57
Table 34.	CN8 microSD™ connector	58
Table 35.	CN11 STDC14 debugging connector	58
Table 36.	CN12 trace debugging connector	59
Table 37.	CN15 TAG debugging connector	59
Table 38.	CN17 JTAG/SWD debugging connector	60
Table 39.	CN21 USB Micro-B connector (front view)	61
Table 40.	CN22 CAN D-type 9-pin male connector	62
Table 41.	STM32L4R9I-EVAL I/O assignment	63
Table 42.	Document revision history	71

List of figures

Figure 1.	STM32L4R9I-EVAL hardware block diagram	11
Figure 2.	STM32L4R9I-EVAL board (top side)	12
Figure 3.	STM32L4R9I-EVAL board (top view) with round DSI display MB1314 daughterboard	13
Figure 4.	STM32L4R9I-EVAL board (top view) with TFT LCD MB1315 daughterboard	14
Figure 5.	STM32L4R9I-EVAL board (bottom view)	15
Figure 6.	MB1313 STM32L4R9I-EVAL board	16
Figure 7.	MB1314 DSI display daughterboard	17
Figure 8.	USB composite device	18
Figure 9.	PCB top-side rework for motor control	31
Figure 10.	PCB bottom-side rework for motor control	32
Figure 11.	CN1 motor-control connector (top view)	49
Figure 12.	CN2 EXT_I2C connector (front view)	50
Figure 13.	CN3 USB OTG FS Micro-AB connector (front view).	50
Figure 14.	CN4 analog input-output connector (top view)	51
Figure 15.	RS232 D-sub male connector (front view)	57
Figure 16.	CN8 microSD™ connector (top view)	57
Figure 17.	CN11 STDC14 debugging connector (top view).	58
Figure 18.	CN12 ETM trace debugging connector (top view)	59
Figure 19.	CN17 JTAG/SWD debugging connector (top view)	60
Figure 20.	CN18 power-supply connector (front view)	61
Figure 21.	CN21 USB Micro-B connector (front view)	61
Figure 22.	CN22 CAN D-type 9-pin male connector (front view)	62

1 Features

- STM32L4R9AI16 Arm^{®(a)}-based microcontroller with 2 Mbytes of Flash memory and 640 Kbytes of RAM in a UFBGA169 package
- 1.2" 390x390 pixels MIPI DSISM round LCD
- 4.3" 480x272 pixels TFT LCD with RGB mode
- Two ST-MEMS digital microphones
- 8-Gbyte microSD[™] card bundled
- 16-Mbit (1 M x 16 bit) SRAM device
- 128-Mbit (8 M x 16 bit) NOR Flash memory device
- 512-Mbit Octo-SPI Flash memory device with double transfer rate (DTR) support
- 64-Mbit Octo-SPI SRAM memory device with HyperBus interface support
- EEPROM supporting 1 MHz I²C-bus communication speed
- Reset and wake-up/tamper buttons
- Joystick with four-way controller and selector
- Touch-sensing button
- Light-dependent resistor (LDR)
- Potentiometer
- Coin battery cell for power backup
- Board connectors:
 - Two jack outputs for a stereo audio headphone with independent content
 - Slot for microSD[™] card supporting SD and SDHC
 - TFT LCD standard connector
 - MIPI DSISM display standard connector
 - EXT_I2C connector supports I²C bus
 - RS-232 port configurable for communication or MCU flashing
 - USB OTG FS Micro-AB port
 - CAN 2.0A/B-compliant port
 - Connector for ADC input and DAC output
 - JTAG/SWD connector
 - ETM trace debug connector
 - User interface through USB virtual COM port
 - Embedded ST-LINK/V2-1 debug and flashing facility
 - TAG connector
 - STDC14 connector
 - PMOD connector
 - Extension connector for the daughterboard
 - Motor-control connector on the daughterboard
- Flexible power-supply options: power jack, ST-LINK/V2-1 USB connector,

a. Arm is a registered trademark of Arm Limited (or its subsidiaries) in the US and/or elsewhere.

USB OTG FS connector, daughterboard

- On-board ST-LINK/V2-1 debugger/programmer with USB re-enumeration capability: mass storage, virtual COM port and debug port
- Microcontroller supply voltage: fixed 3.3 V or adjustable range from 1.71 V to 3.6 V
- MCU current consumption measurement circuit
- Access to the comparator and operational amplifier of STM32L4R9AI6
- Comprehensive free software libraries and examples available with the STM32Cube package
- Support of a wide choice of integrated development environments (IDEs) including IAR Embedded Workbench[®], MDK-ARM, and STM32CubeIDE



2 Ordering information

To order the STM32L4R9I-EVAL Evaluation board, refer to [Table 1](#). Additional information is available from the datasheet and reference manual of the target STM32.

Table 1. Ordering information

Order code	Board reference	Targeted STM32
STM32L4R9I-EVAL	<ul style="list-style-type: none"> – MB1313 – MB1314⁽¹⁾ – MB1315⁽²⁾ 	STM32L4R9AI6

1. DSI display daughterboard
2. TFT LCD daughterboard

2.1 Codification

The meaning of the codification is explained in [Table 2](#).

Table 2. Codification explanation

STM32XXYY-EVAL	Description	Example: STM32L4R9I-EVAL
XX	MCU series in STM32 Arm Cortex MCUs	STM32L4 Series
YY	STM32 product line in the series	STM32L4R9
I	STM32 Flash memory size: – I for 2 Mbytes	2 Mbytes

3 Development environment

3.1 System requirements

- Windows® OS (7, 8, and 10), Linux® 64-bit, or macOS®(a)
- USB Type-A or USB Type-C® to Micro-B cable

3.2 Development toolchains

- IAR Systems - IAR Embedded Workbench®(b)
- Keil® - MDK-ARM(b)
- STMicroelectronics - STM32CubeIDE

3.3 Demonstration software

The demonstration software, included in the STM32Cube MCU Package corresponding to the on-board microcontroller, is preloaded in the STM32 Flash memory for easy demonstration of the device peripherals in standalone mode. The latest versions of the demonstration source code and associated documentation can be downloaded from www.st.com.

4 Delivery recommendations

Before the first use, make sure that no damage occurred to the boards during shipment and no socketed components are loosen in their sockets or fallen into the plastic bag.

In particular, pay attention to the following components:

1. microSD™ card in its CN8 receptacle
2. DSI display MB1314 daughterboard in its CN16 connector

For product information related to the STM32L4R9AI16 microcontroller, visit www.st.com website.

5 Technology partners

MACRONIX: 512-Mbit Octo-SPI Flash, part number MX25LM51245GXDI00

-
- a. macOS® is a trademark of Apple Inc. registered in the U.S. and other countries.
 - b. On Windows only

6 Hardware layout and configuration

The STM32L4R9I-EVAL board is designed around the STM32L4R9AI16 target microcontroller in a UFBGA 169-pin package. *Figure 1* illustrates the STM32L4R9AI16 connections with peripheral components. *Figure 2* shows the location of the main components on the Evaluation board. *Figure 3*, *Figure 4*, and *Figure 5* are the three images showing the STM32L4R9I-EVAL board top view with round DSI display, top view with TFT LCD, and bottom view.

Figure 1. STM32L4R9I-EVAL hardware block diagram






Figure 2. STM32L4R9I-EVAL board (top side)




6.1 STM32L4R9I-EVAL board views

Figure 3. STM32L4R9I-EVAL board (top view) with round DSI display MB1314 daughterboard




Picture is not contractual

Figure 4. STM32L4R9I-EVAL board (top view) with TFT LCD MB1315 daughterboard



Picture is not contractual

Figure 5. STM32L4R9I-EVAL board (bottom view)



Picture is not contractual

6.2 Mechanical dimensions

Figure 6. MB1313 STM32L4R9I-EVAL board





Figure 7. MB1314 DSI display daughterboard



6.3 ST-LINK/V2-1

ST-LINK/V2-1 facility for debugging and flashing of the STM32L4R9AI16 is integrated on the STM32L4R9I-EVAL board.

Compared to the ST-LINK/V2 stand-alone tool available from STMicroelectronics, ST-LINK/V2-1 offers new features and drops some others.

New features:

- USB software re-enumeration
- Virtual COM port interface on USB
- Mass storage interface on USB
- USB power management request for more than 100mA power on USB

Features dropped:

- SWIM interface

The CN21 USB connector can be used to power STM32L4R9I-EVAL regardless of the ST-LINK/V2-1 facility use for debugging or for flashing STM32L4R9AI16. This holds also when the ST-LINK/V2 stand-alone tool is connected to CN12, CN17, CN11, or CN15 connector and used for debugging or flashing STM32L4R9AI16. [Section 6.5](#) provides more details on powering STM32L4R9I-EVAL.


For full detail on both versions of the debug and flashing tool, the stand-alone ST-LINK/V2 and the embedded ST-LINK/V2-1, refer to www.st.com.

6.3.1 Drivers

Before connecting STM32L4R9I-EVAL to a Windows (XP, 7, 8 10) PC via USB, a driver for ST-LINK/V2-1 must be installed. It is available from www.st.com.

In case the STM32L4R9I-EVAL board is connected to the PC before installing the driver, the Windows device manager may report some USB devices found on STM32L4R9I-EVAL as “Unknown”. To recover from this situation, after installing the dedicated driver downloaded from www.st.com, the association of “Unknown” USB devices found on STM32L4R9I-EVAL to this dedicated driver must be updated in the device manager manually. It is recommended to proceed using the USB Composite Device line, as shown in [Figure 8](#).

Figure 8. USB composite device



6.3.2 ST-LINK/V2-1 firmware upgrade

For its operation, ST-LINK/V2-1 employs a dedicated MCU with Flash memory. Its firmware determines ST-LINK/V2-1 functionality and performance. The firmware may evolve during the life span of STM32L4R9I-EVAL to include new functionality, fix bugs, or support new target microcontroller families. It is therefore recommended to keep ST-LINK/V2-1 firmware up to date. The latest version is available from www.st.com.

6.4 ETM trace

The CN12 connector is available to output trace signals used for debugging. By default, the Evaluation board is configured such that, STM32L4R9AI16 signals PE2, PE5, and PE6 are not connected to trace outputs Trace_CK, Trace_D2, and Trace_D3 of CN12. They are used for other functions.

[Table 3](#) shows the setting of configuration elements to shunt PE2, PE5, and PE6 MCU ports to the CN12 connector, to use them as debug trace signals.

Table 3. Setting of configuration elements for CN12 trace connector

Element	Setting	Configuration
R53 SB56	R53 in SB56 open	Default setting. PE2 connected to memory address line A23.
	R53 out SB56 closed	PE2 connected to Trace_CK on CN12. A23 pulled down.
R209 SB59	R209 in SB59 open	Default setting. PE5 connected to memory address line A21.
	R209 out SB59 closed	PE5 connected to Trace_D2 on CN12. A21 pulled down.
R211 SB60	R211 in SB60 open	Default setting. PE6 connected to memory address line A22.
	R211 out SB60 closed	PE6 connected to Trace_D3 on CN12. A22 pulled down.

Warning: Enabling the CN12 trace outputs through hardware modifications described in [Table 3](#) results in reducing the memory address bus width to 20 address lines and so the addressable space to 1 Mword of 16 bits. As a consequence, the onboard SRAM and NOR Flash memory usable capacity is reduced to 16 Mbits.

6.5 Power Supply

The STM32L4R9I-EVAL board is designed to be powered from 5 V DC power source. It incorporates a precise polymer Zener diode (Poly-Zen) protecting the board from damage due to the wrong power supply. One of the following four 5 V DC power inputs is usable with an appropriate board configuration:

- Power jack CN18 marked PSU_DC5V on the board. A jumper must be placed in E5V location of JP11. The positive pole is on the center pin as illustrated in [Figure 20](#).
- Micro-B USB receptacle CN21 of ST-LINK/V2-1 provides up to 500mA to the board. Offering enumeration feature described in [Section 6.5.1](#).
- Micro-AB USB receptacle CN3 of USB OTG interface marked USB_OTG_FS on the board, supplies up to 500mA to the board.
- Pin 39 of CN5 and Pin 39 of CN6 extension connectors for a custom daughterboard, marked D5V on the board.

No external power supply is provided with the board.

LD7 red LED turns on when the voltage on the power line marked as +5 V is present. All supply lines required for the operation of the components on STM32L4R9I-EVAL are derived from that +5 V line.

[Table 4](#) describes the setting of all jumpers related to powering the STM32L4R9I-EVAL and its extension board. VDD_MCU is STM32L4R9AI16 digital supply voltage line. It is possible to drive the boards with either fixed 3.3 V or with an adjustable voltage regulator controlled by RV3 potentiometer and producing a range of voltages between 1.71 V and 3.6 V.

6.5.1 Supplying the board through ST-LINK/V2-1 USB port

To power STM32L4R9I-EVAL in this way, the USB host (a PC) gets connected with the STM32L4R9I-EVAL board's Micro-B USB receptacle, via a USB cable. This event is the beginning of the USB enumeration procedure. In its initial phase, the host's USB port current supply capability is limited to 100 mA. It is enough because only the ST-LINK/V2-1 part of STM32L4R9I-EVAL draws power at that time. If the SB33 solder bridge is open, the U22 ST890 power switch is set in the OFF position, which isolates the remainder of STM32L4R9I-EVAL from the power source. In the next phase of the enumeration procedure, the host PC informs the ST-LINK/V2-1 facility of its capability to supply up to 300 mA of current. If the answer is positive, the ST-LINK/V2-1 sets the U22 ST890 switch to ON position to supply power to the remainder of the STM32L4R9I-EVAL board. If the PC USB port is not capable of supplying up to 300 mA of current, the CN18 power jack is available to supply the board.

If a short-circuit occurs on the board, the ST890 power switch protects the USB port of the host PC against a current exceeding 600 mA. In such an event, the LD8 LED lights on.

The STM32L4R9I-EVAL board is also supply-able from a USB power source not supporting enumeration, such as a USB charger, as shown in [Table 4](#). ST-LINK/V2-1 turns the ST890 power switch ON regardless of the enumeration procedure result and passes the power unconditionally to the board.

The LD7 red LED turns on whenever the whole board is powered.

6.5.2 Using ST-LINK/V2-1 along with powering through the CN18 power jack

If the board requires more than 300 mA of supply current, this cannot be provided by the host PC connected to the ST-LINK/V2-1 USB port, used for debugging or flashing STM32L4R9AI16. In such a case, the board is supplied through CN18 (marked PSU_DC5V on the board).

To do this, it is important to power the board before connecting it with the host PC, which requires the following sequence to be respected:

1. Set the jumper in JP11 header in E5V position,
2. Connect the external 5 V power source to CN18,
3. Check the red LED LD7 is turned on,
4. Connect the host PC to the CN12 USB connector.

In case the board requires more than 300 mA and the host PC is connected via USB before the board is powered from CN18, there is a risk of the following events to occur, in the order of severity:

1. The host PC is capable of supplying 300 mA (the enumeration succeeds) but it does not incorporate any over-current protection on its USB port. It is damaged due to over-current.
2. The host PC is capable of supplying 300 mA (the enumeration succeeds) and it has built-in over-current protection on its USB port, limiting or shutting down the power out of its USB port when the excessive current requirement from STM32L4R9I-EVAL is detected. This causes an operating failure to STM32L4R9I-EVAL.
3. The host PC is not capable of supplying 300 mA (the enumeration fails) so ST-LINK/V2-1 does not supply the remainder of STM32L4R9I-EVAL from its USB port V_{BUS} line.

Table 4. Power supply related jumpers settings
















Jumper / solder bridge	Setting	Configuration
JP11 Power source selector		STM32L4R9I-EVAL is supplied through the CN18 power jack (marked PSU_DC5V). CN5 and CN6 extension connectors do not pass the 5 V of STM32L4R9I-EVAL to the daughterboard.
		STM32L4R9I-EVAL is supplied through the CN3 Micro-AB USB connector. CN5 and CN6 extension connectors do not pass the 5 V of STM32L4R9I-EVAL to the daughterboard.
		Default setting. STM32L4R9I-EVAL is supplied through the CN21 Micro-B USB connector. CN5 and CN6 extension connectors do not pass the 5 V of STM32L4R9I-EVAL to the daughterboard.
		STM32L4R9I-EVAL is supplied through pin 39 of CN5 and pin 39 of CN6 extension connectors.
		STM32L4R9I-EVAL is supplied through the CN18 power jack. CN5 and CN6 extension connectors pass the 5 V of STM32L4R9I-EVAL to the daughterboard. Make sure to disconnect from the daughterboard, any power supply that may generate conflict with the power supply on the CN18 power jack.
JP8 Vbat connection		Vbat is connected to the battery.
		Default setting. Vbat is connected to VDD.
JP10 VDD_MCU connection		Default setting. VDD_MCU (VDD terminals of STM32L4R9AI16) is connected to fixed +3.3 V.
		VDD_MCU is connected to voltage in the range from +1.71 V to +3.6 V, adjustable with potentiometer RV3.
JP1 VDD_USB connection		Default setting. VDD_USB (VDD USB terminal of STM32L4R9AI16) is connected with VDD_MCU.
		VDD_USB is connected to +3.3 V.

Table 4. Power supply related jumpers settings (continued)

Jumper / solder bridge	Setting	Configuration
JP2 VDDA connection		Default setting. VDDA terminal of STM32L4R9AI6 is connected with VDD_MCU.
		VDDA terminal of STM32L4R9AI6 is connected to +3.3 V.
JP3 VDD_IO connection		Default setting. VDD_IO (VDDIO2 terminals of STM32L4R9AI6) is connected with VDD_MCU.
		VDD_IO is open.
SB33 Powering through USB of ST-LINK/ V2-1	SB33 Off	Default setting. The CN21 ST-LINK/V2-1 Micro-B USB connector can be used to supply power to the STM32L4R9I-EVAL board remainder, depending on the powering capability of the host PC USB port declared in the enumeration.
	SB33 On	CN21 Micro-B USB connector of ST-LINK/V2-1 supplies power to the STM32L4R9I-EVAL board remainder. This is the setting for powering the board through CN21 using a USB charger ⁽¹⁾ .

1. On all ST-LINK/V2-1 boards, the target application is now able to run even if the ST-LINK/V2-1 is either not connected to a USB host, or is powered through a USB charger (or through a not-enumerating USB host).

6.6 Clock references

Two clock references are available on STM32L4R9I-EVAL for the STM32L4R9AI6 microcontroller.

- 32.768 kHz crystal X1, for embedded RTC
- 25 MHz crystal X2, for the main clock generator

The main clock generation is possible via an internal RC oscillator, disconnected by removing resistors R61 and R65 when the internal RC clock is used.

Table 5. X1 crystal related solder bridge settings

Solder bridge	Setting	Configuration
SB50	Open	Default setting. PC14 OSC32_IN terminal is not routed to the CN5 extension connector. X1 is used as the clock reference.
	Closed	PC14 OSC32_IN is routed to the CN5 extension connector. Resistor R50 must be removed, for the X1 quartz circuit not to disturb the clock reference or source on the daughterboard.

Table 5. X1 crystal related solder bridge settings (continued)

Solder bridge	Setting	Configuration
SB49	Open	Default setting. PC15 OSC32_OUT terminal is not routed to the CN5 extension connector. X1 is used as the clock reference.
	Closed	PC15 OSC32_OUT is routed to the CN5 extension connector. Resistor R49 must be removed, for the X1 quartz circuit not to disturb clock reference on the daughterboard.

Table 6. X2 crystal related solder bridge settings

Solder bridge	Setting	Configuration
SB52	Open	Default setting. PH0 OSC_IN terminal is not routed to the CN5 extension connector. X2 is used as the clock reference.
	Closed	PH0 OSC_IN is routed to the CN5 extension connector. Resistor R61 must be removed, in order not to disturb clock reference or source on the daughterboard.
SB53	Open	Default setting. PH1 OSC_OUT terminal is not routed to the CN5 extension connector. X2 is used as the clock reference.
	Closed	PH1 OSC_OUT is routed to the CN5 extension connector. Resistor R65 must be removed, in order not to disturb clock reference or source on the daughterboard.

6.7 Reset sources

The reset signal of the STM32L4R9I-EVAL board is active LOW.

Sources of reset are listed below:

- reset button B2
- CN17 JTAG/SWD connector, CN12 ETM trace connector, CN11 STDC14 connector and CN15 TAG connector (reset from debug tools)
- reset through pin 27 of CN6 extension connector (reset from daughterboard)
- embedded ST-LINK/V2-1

6.8 Boot option

After reset, the STM32L4R9AI16 MCU boot is available from the following embedded memory locations:

- main (user, non-protected) Flash memory
- system (protected) Flash memory
- RAM, for debugging

The boot option is configured by setting switch SW1 (BOOT) and the boot base address programmed in the nBOOT1, nBOOT0, and nSWBOOT0 of FLASH_OPTR option bytes.

Table 7. Boot selection switch

Switch	Setting	Description
SW1	<p>0<->1</p>	Default setting. BOOT0 line is tied low. STM32L4R9AI16 boots from main Flash memory or system memory.
	<p>0<->1</p>	BOOT0 line is tied high. STM32L4R9AI16 boots from system Flash memory (nBOOT1 bit of FLASH_OPTR register is set high) or from RAM (nBOOT1 is set low).

6.8.1 Bootloader limitations

Boot from system Flash memory results in executing bootloader code stored in the system Flash memory protected against writing and erasing. This allows in-system programming (ISP), that is, flashing the STM32 user Flash memory. It also allows writing data into RAM. The data come in via one of the communication interfaces such as USART, SPI, I2C bus, USB, or CAN.

The bootloader version is identified by reading the Bootloader ID at the address 0x1FFF6FFE: the content is 0x91 for bootloader V9.1 and 0x92 for V9.2.

The STM32L4R9AI16 part soldered on the STM32L4R9I-EVAL main board is marked with a date code corresponding to its date of manufacturing. STM32L4R9AI16 parts with a date code prior or equal to week 37 of 2017 are fitted with bootloader V9.1 affected by the limitations to be worked around, as described hereunder. Parts with the date code starting from week 38 of 2017 contain bootloader V9.2 in which the limitations no longer exist.

To locate the visual date code information on the STM32L4R9I16 package, refer to its datasheet (DS12023) available at www.st.com, section Package Information. Date code related portion of the package marking takes Y WW format, where Y is the last digit of the year and WW is the week. For example, a part manufactured in week 38 of 2017 bares the date code 7 38.

There is also another way to identify the need for a workaround: before opening the blister of the Discovery Kit, just check the backside of the blister. At the bottom left side, if the reference number is equal or higher than 32L4R9IDISCO/ 02-0, it means the bootloader version is V9.2 and there is no need to apply a workaround. Any other inferior number like 01-0 needs the workaround.

The bootloader ID for the bootloader V9.1 is 0x91.

The following limitation exists in the bootloader V9.1:

Some user Flash memory data get corrupted when written via SPI interface

Description:

During bootloader SPI Write Flash operation, some random 64-bits (2 double-words) may be left blank at 0xFF.

Workarounds:

WA1: add a delay between sending the Write command and its ACK request. Its duration must be the duration of the 256-Byte Flash write time.

WA2: read back after each writing operation (256 bytes or at end of user code flashing) and in case of error start writing again.

WA3: Using bootloader, load a patch code in RAM to write in Flash memory through the same Write Memory write protocol as bootloader (code provided by ST).

6.9 Audio

A codec connected to the STM32L4R9AI16 SAI interface supports the DSAI port TDM feature. This offers STM32L4R9AI16 the capability to simultaneously stream two independent stereo audio channels to two separate stereo analog audio outputs.

There are two digital microphones on the STM32L4R9I-EVAL board.

6.9.1 Digital microphones





U30 and U31 on the STM32L4R9I-EVAL board are MP34DT01TR MEMS digital omnidirectional microphones providing PDM (pulse density modulation) outputs. To share the same data line, their outputs are interlaced. The combined data output of the microphones is directly routed to STM32L4R9AI16 terminals, thanks to the integrated input digital filters. The microphones are supplied with a programmable clock generated directly by STM32L4R9AI16.

As an option, the microphones are connected to U26 WM8994, the Wolfson audio codec device. In that configuration, U26 also supplies the PDM clock to the microphones.

Regardless of where the microphones are routed to, STM32L4R9AI16 or WM8994, their power supplier is either VDD or MICBIAS1 output of the WM8994 codec device.

[Table 8](#) shows the settings of all jumpers associated with the digital microphones on the board.

Table 8. Digital microphone-related jumper settings

Jumper	Setting	Configuration
JP16		The PDM clock for digital microphones comes from the WM8994 codec.
		Default setting. The PDM clock for digital microphones comes from STM32L4R9AI16.
JP15		The power supply of digital microphones is generated by WM8994 codec.
		Default setting. The power supply of digital microphones is V _{DD} .

6.9.2 Headphones outputs

The STM32L4R9I-EVAL board potentially drives two sets of stereo headphones. Identical or different stereo audio contents are played back in each set of headphones. STM32L4R9AI16 sends up to two independent stereo audio channels, via its SAI1 TDM port, to the WM8994 codec device. The codec device converts the digital audio stream to stereo analog signals. It then boosts them for direct drive of headphones connecting to 3.5 mm stereo jack receptacles on the board, CN24 for Audio-output1, and CN23 for Audio_output2.

The CN23 jack takes its signal from the output of the WM8994 codec device intended for driving an amplifier for loudspeakers. A hardware adaptation is incorporated on the board to make it compatible with a direct headphone drive. The adaptation consists of coupling capacitors blocking the DC component of the signal, attenuator, and anti-pop resistors. The loudspeaker output of the WM8994 codec device must be configured by software in a linear mode called “class AB” and not in a switching mode called “class D”.

The I²C-bus address of WM8994 is `0b0011 010x`.

6.9.3 Limitations in using audio features

Due to the share of some terminals of STM32L4R9AI16 by multiple peripherals, the following limitations apply in using the audio features:

- If the SAI1_MCLKA and SAI1_FSA are used as part of SAI1 port, it cannot be used as CAN peripheral.
- If the SAI1_SDB is used as part of the SAI1 port, it cannot be used as the Comp2_OUT signal.
- If the SAI1 port of STM32L4R9AI16 is used for streaming audio to the WM8994 codec IC, STM32L4R9AI16 cannot control the motor.
- If the digital microphones are attached to STM32L4R9AI16, control the motor cannot be driven.

6.10 USB OTG FS port

The STM32L4R9I-EVAL board supports USB OTG full-speed (FS) communication. The CN3 USB OTG connector is Micro-AB type.

6.10.1 STM32L4R9I-EVAL used as a USB device

When a “USB host” connection to the CN3 Micro-AB USB connector of STM32L4R9I-EVAL is detected, the board starts behaving like a “USB device”. Depending on the powering capability of the USB host, the board potentially takes power from the V_{BUS} terminal of CN3. In the board schematic diagrams, the corresponding power voltage line is called U5V.

[Section 6.5](#) provides information on how to set associated jumpers for this powering option. The resistor R23 must be left open to prevent STM32L4R9I-EVAL from sourcing 5 V to the V_{BUS} terminal, which would cause conflict with the 5 V sourced by the USB host. This may happen if the MFX_GPIO6 is controlled by the software of the MFX MCU such that, it enables the output of the U2 power switch.

6.10.2 STM32L4R9I-EVAL used as a USB host

When a “USB device” connection to the CN3 Micro-AB USB connector is detected, the STM32L4R9I-EVAL board starts behaving like a “USB host”. It sources 5 V on the V_{BUS} terminal of the CN3 Micro-AB USB connector to power the USB device. For this to happen, the STM32L4R9AI16 sets the U2 power switch STMP2151STR to ON state. The LD6 green LED marked OTG_FS indicates that the peripheral is supplied from the board. The LD5 red LED marked FS_OC lights up if over-current is detected. The resistor R23 must be closed to allow the MFX_GPIO6 from MFX MCU to control the U2 power switch.

In any other STM32L4R9I-EVAL powering option, the resistor R23 must be open, to avoid accidental damage caused to an external USB host.

6.10.3 Limitations in using USB OTG FS port

The USB OTG FS port operation is exclusive with motor control

6.10.4 Operating voltage

The USB-related operating supply voltage of STM32L4R9AI16 (VDD_{USB} line) must be within the range from 3.0 V to 3.6 V.

6.11 RS232 port

The STM32L4R9I-EVAL board offers one RS-232 communication port. The RS-232 communication port uses the CN7 DB9 male connector. RX, TX, RTS, and CTS signals of the STM32L4R9AI16 LPUSART1 interface are routed to CN7.

6.11.1 Operating voltage

The RS-232 operating supply voltage of STM32L4R9AI16 (VDD line) must be within the range from 1.71 V to 3.6 V.

6.12 microSD™ card

The CN8 slot for microSD™ card is routed to STM32L4R9AI16 SDIO port, accepting SD (up to 2 Gbytes) and SDHC (up to 32 Gbytes) cards. One 8-Gbyte microSD™ card is delivered as part of STM32L4R9I-EVAL. The card insertion switch is routed to the MFX_GPIO5 of MFX MCU port.

6.12.1 Limitations

Due to the share of SDIO port, the following limitations apply:

- The microSD™ card cannot be operated simultaneously with motor control.
- The microSD™ card cannot be operated for 4 bits data when SDIO_D1 and SDIO_D2 used as Trace_D0 and Trace_D1 signals.

6.12.2 Operating voltage

The supply voltage for the STM32L4R9I-EVAL microSD™ card operation must be within the range from 2.7 V to 3.6 V.

6.13 Motor control

The CN1 connector is designed to receive a motor-control (MC) module. [Table 9](#) shows the assignment of CN1 and STM32L4R9AI16 terminals.

[Table 9](#) also lists the modifications to be made on the board versus its by-default configuration. Refer to [Section 6.13.1](#) for further details.

Table 9. Motor-control terminal and function assignment

CN1 motor-control connector		STM32L4R9AI16 microcontroller			
Terminal	Terminal name	Port name	Function	Alternate function	Board modifications for enabling motor control
1	Emergency Stop	PI4	TIM8_BKIN	-	Close SB3. Remove R234.
2	GND	-	GND	-	-
3	PWM_1H	PC6	TIM8_CH1	-	Close SB21. Remove R44 or no daughterboard.
4	GND	-	GND	-	-
5	PWM_1L	PH13	TIM8_CH1N	-	Close SB46. Remove R186.
6	GND	-	GND	-	-
7	PWM_2H	PC7	TIM8_CH2	-	Close SB19. Open SB20. Remove R46 or no daughterboard.
8	GND	-	GND	-	-
9	PWM_2L	PH14	TIM8_CH2N	-	Close SB44. Remove R185.
10	GND	-	GND	-	-
11	PWM_3H	PC8	TIM8_CH3	-	Close SB2. Remove R195.
12	GND	-	GND	-	-
13	PWM_3L	PH15	TIM8_CH3N	-	Close SB45. Remove R184.
14	Bus Voltage	PC4	ADC1_IN13	-	Close SB55. Remove R75.
15	PhaseA current+	PC0	ADC1_IN1	-	Close SB36. Remove R242.
16	PhaseA current-	-	GND	-	-

Table 9. Motor-control terminal and function assignment (continued)

CN1 motor-control connector		STM32L4R9AI16 microcontroller			
Terminal	Terminal name	Port name	Function	Alternate function	Board modifications for enabling motor control
17	PhaseB current+	PC1	ADC1_IN2	-	Close SB37. Remove R244.
18	PhaseB current-	-	GND	-	-
19	PhaseC current+	PC2	ADC1_IN3	-	Close SB43. Remove R217.
20	PhaseC current-	-	GND	-	-
21	ICL Shutout	PG9	GPIO	-	Close SB34. Remove R236.
22	GND	-	GND	-	-
23	Dissipative Brake	PG13	GPIO	-	Close SB47. Remove SB29 and no board on the PMOD connector.
24	PFC indirect current	PA0	ADC1_IN5	-	Close SB38 Remove R214 and SB39
25	+5V	-	+5V	-	-
26	Heatsink Temp.	PA1	ADC1_IN6	-	Close SB40. Remove R216.
27	PFC Sync	PB14	TIM15_CH1	-	Close SB41. Remove R207 and no board on the PMOD connector.
28	+3.3V	-	+3.3V	-	-
29	PFC PWM	PB15	TIM15_CH2	-	Close SB51. Remove R187.
30	PFC Shutdown	PA9	TIM15_BKIN	-	Close SB35. Remove R203.
31	Encoder A	PB6	TIM4_CH1	ADC12_IN	Close SB14. Remove SB15 and SB16. Remove R26 or no daughterboard.
32	PFC Vac	PC3	ADC1_IN4	-	Close SB54. Remove R67.

Table 9. Motor-control terminal and function assignment (continued)

CN1 motor-control connector		STM32L4R9AI16 microcontroller			
Terminal	Terminal name	Port name	Function	Alternate function	Board modifications for enabling motor control
33	Encoder B	PB7	TIM4_CH2	ADC12_IN	Close SB17. Remove SB18. Remove R30 or no daughterboard.
34	Encoder Index	PB8	TIM4_CH3	ADC12_IN	Close SB42. Remove R235 and open JP12.

6.13.1 Board modifications to enable motor control

Figure 9 (top side) and *Figure 10* (bottom side) illustrate the board modifications listed in *Table 9*, required for the operation of motor control. The red color denotes a component to be removed. The green color denotes a component to be fitted.

6.13.2 Limitations

Motor-control operation is exclusive with Octo-SPIP1 Flash memory device, audio codec, potentiometer, LDR, microSD™ card, LED1 to LED4 drive, MEMS, MFX, PMOD, USB OTG_FS, TFT LCD connector, DSI display connector, and touch sensing.

Figure 9. PCB top-side rework for motor control





Figure 10. PCB bottom-side rework for motor control









6.14 CAN

The STM32L4R9I-EVAL board supports one CAN2.0A/B channel compliant with CAN specification. The CN22 DB9 male connector is available as the CAN interface.

A 3.3 V CAN transceiver is fitted between the CN22 connector and the CAN controller port of STM32L4R9AI16.

The JP14 jumper selects one of the high-speed, standby, and slope control modes of the CAN transceiver. The JP13 jumper allows integrating a CAN termination resistor. The JP12 is used to connected the CAN transceiver avoiding unknown signals from the CAN transceiver.

Table 10. CAN related jumpers

Jumper	Setting	Configuration
JP14		Default setting. CAN transceiver operates in high-speed mode.
		CAN transceiver is in standby mode.
JP13		Default setting. Termination resistor fitted on CAN physical link.
		No termination resistor on CAN physical link.
JP12		Default setting. CAN_TX is not used for CAN transceiver.
		CAN_TX is used from the STM32L4R9AI16 terminal.

6.14.1 Limitations

CAN operation is exclusive with the audio codec and MC operation.

6.14.2 Operating voltage

The supply voltage for STM32L4R9I-EVAL CAN operation must be within the range from 3.0 V to 3.6 V.

6.15 Extension connectors CN5, CN6, CN13, and CN14

The CN5, CN6, CN13, and CN14 headers complement to give access to all GPIOs of the STM32L4R9AI16 microcontroller. In addition to GPIOs, the following signals and power supply lines are also routed on CN5 or CN6 or CN13 or CN14:

- GND
- +5 V
- +3.3 V
- D5V
- VDD
- RESET#
- Clock terminals PC14-OSC32_IN, PC15-OSC32_OUT, PH0-OSC_IN, PH1-OSC_OUT

Each header has two rows of 20 pins, with 1.27 mm pitch and 2.54 mm row spacing. For extension modules, SAMTEC RSM-120-02-L-D-xxx and SMS-120-x-x-D are recommendable as SMD and through-hole receptacles, respectively (x is a wild card).

6.16 User LEDs

Four general-purpose color LEDs (LD1, LD2, LD3, LD4) are available as light indicators. Each LED is ON with a low level of the corresponding ports of STM32L4R9AI16.

And the four LEDs are exclusive with MC operation.

6.17 Physical input devices









The STM32L4R9I-EVAL board provides several input devices for physical human control, listed below:

- four-way joystick controller with select key (B1)
- wake-up/ tamper button (B3)
- reset button (B2)
- 10 k Ω potentiometer (RV2)
- light-dependent resistor, LDR (R121)

The potentiometer and the light-dependent resistor are mutually exclusively rout-able to either PB4 or PA0 port of STM32L4R9AI16. [Table 11](#) depicts the setting of associated configuration jumpers.

As illustrated in the schematic diagram, the PB4 port is routed, in the STM32L4R9AI16, to the non-inverting input of comparator Comp2. The PA0 is routed to the non-inverting input of the operational amplifier OpAmp1.

Table 11. Port assignment for control of physical input devices

Jumper	Setting	Routing
JP9		A potentiometer is routed to pin PB4 of STM32L4R9AI16.
JP5		
JP9		Default setting. A potentiometer is routed to pin PA0 of STM32L4R9AI16.
JP5		
JP9		LDR is routed to pin PB4 of STM32L4R9AI16.
JP5		
JP9		LDR is routed to pin PA0 of STM32L4R9AI16.
JP5		

6.17.1 Limitations

The potentiometer and the light-dependent resistor are exclusive with MFX, audio codec, OctoSPIP1, the debugging connector, and MC operation. They are mutually exclusive.

6.18 Operational amplifier and comparator

6.18.1 Operational amplifier

STM32L4R9AI16 provides two onboard operational amplifiers, one of which, OpAmp1, is made accessible on STM32L4R9I-EVAL. OpAmp1 has its inputs and its output routed to I/O ports PA0, PA1, and PA3, respectively. The non-inverting input PA0 is accessible on the terminal 1 of the JP5 jumper header. On top of the possibility of routing either of the potentiometer or LDR to PA0, an external source is also connectible to it, using the terminal 1 of JP5.

The PA3 output of the operational amplifier is accessible on test point TP9. Refer to the schematic diagram.

The gain of OpAmp1 is determined by the ratio of the variable resistor RV1 and the resistor R246, as shown in the following equation:

$$\text{Gain} = 1 + \text{RV1} / \text{R246}$$

With the RV1 ranging from 0 to 10 kΩ and R246 being 1 kΩ, the gain varies from 1 to 11.

The R108 resistor in series with PA0 is beneficial for reducing the output offset.

Table 12 shows the configuration elements and their settings allowing them to access the OpAmp1 function.

Table 12. Configuration elements related to OpAmp1

Element	Setting	Configuration
SB39 SB38 R214	SB38 open SB39 closed R214 out	OpAmp1_INP is routed to pin PA0 of STM32L4R9AI16.
	SB38 open SB39 closed R214 in	Default setting. PA0 port of STM32L4R9AI16 is routed to MFX_IRQ_OUT or motor control signal.
	SB38 closed SB39 open R214 out	PA0 port of STM32L4R9AI16 is routed to the motor-control signal.
R216 SB40	R216 in SB40 open	Default setting. OpAmp1_INM is routed to pin PA1 of STM32L4R9AI16.
	R216 out SB40 closed	PA1 port of STM32L4R9AI16 is routed to the motor-control signal.
R215 R221	R215 in R221 out	OpAmp1_VOUT is routed to pin PA3 of STM32L4R9AI16.
	R215 out R221 in	Default setting. OpAmp1_VOUT is not routed to pin PA3 of STM32L4R9AI16. PA3 port of STM32L4R9AI16 is routed to OctoSPI1_CLK.

6.18.2 Comparator

STM32L4R9AI16 provides two onboard comparators, one of which, Comp2, is made accessible on STM32L4R9I-EVAL. Comp2 has its non-inverting input and its output routed to I/O ports PB4 and PB5, respectively. The input is accessible on the terminal 3 of the JP5 jumper header. On top of the possibility of routing either the potentiometer or LDR to PB4, an external source is connectible to it, using the terminal 3 of JP5.

The PB5 output of the comparator is accessible on test point TP6. Refer to the schematic diagram.

Table 13 shows the configuration elements and their settings allowing them to access the Comp2 function.

Table 13. Configuration elements related to Comp2

Element	Setting	Configuration
R200 SB22	R200 out SB22 closed	Default setting. Comp2_INP is routed to pin PB4 of STM32L4R9AI16.
	R200 in SB22 open	PB4 port of STM32L4R9AI16 is routed to the TRST signal.

Table 13. Configuration elements related to Comp2 (continued)

Element	Setting	Configuration
R204 SB48	R204 out SB48 open	Comp2_OUT is routed to pin PB5 of STM32L4R9AI16.
	R204 in SB48 closed	Default setting. Comp2_OUT is not routed to pin PB4 of STM32L4R9AI16. PB4 port of STM32L4R9AI16 is routed to SA11_SDB.

6.18.3 Limitations

The OpAmp1 is exclusive with MFX, OctoSPIP1, and MC operation.

The Comp2 is exclusive with the debugging connector and SA11.

6.19 Analog input, output, VREF

STM32L4R9AI16 provides onboard analog-to-digital converter ADC, and digital-to-analog converter DAC. The port PA4 is configurable to operate either as ADC input or as DAC output. PA4 is routed to the two-way header CN4 allowing to fetch signals to or from PA4 or to ground it by fitting a jumper into CN4.

Parameters of the ADC input low-pass filter formed with R31 and C21 are adjustable by replacing these components according to application requirements. Similarly, parameters of the DAC output low-pass filter formed with R32 and C21 are modifiable by replacing these components according to application requirements.

The VREF+ terminal of STM32L4R9AI16 is used as the reference voltage for both ADC and DAC. By default, it is routed to VDDA through a jumper fitted into the two-way header CN10. The jumper is removable and an external voltage applied to the terminal 1 of CN10, for specific purposes.

6.20 SRAM device

IS61WV102416BLL, a 16-Mbit static RAM (SRAM), 1 M x 16 bit, is fitted on the STM32L4R9I-EVAL main board, in U17 position. The STM32L4R9I-EVAL main board, as well as the addressing capabilities of FMC, allow hosting SRAM devices up to 64 Mbytes. This is the reason why the schematic diagram mentions several SRAM devices.

The SRAM device is attached to the 16-bit data bus and accessed with FMC. The base address is $0x6000\ 0000$, corresponding to NOR/SRAM1 bank1. The SRAM device is selected with the FMC_NE1 chip select. FMC_NBL0 and FMC_NBL1 signals allow selecting 8-bit and 16-bit data word operating modes.

By removal of R134, a zero-ohm resistor, the SRAM is deselected and the STM32L4R9AI16 ports PD7, PE0, and PE1 corresponding to FMC_NE1, FMC_NBL0, and FMC_NBL1 signals, respectively, are usable for other application purposes.

Table 14. SRAM chip select configuration

Resistor	Fitting	Configuration
R134	In	Default setting. SRAM chip select is controlled with FMC_NE1
	Out	SRAM is deselected. FMC_NE1 is freed for other application purposes.

6.20.1 Limitations

The SRAM addressable space is limited if some or all of A21 FMC address lines are shunted to the CN12 connector for debug trace purposes. In such a case, the disconnected addressing inputs of the SRAM device are pulled down by resistors. [Section 6.4](#) provides information on the associated configuration elements.

6.20.2 Operating voltage

The SRAM device operating voltage is in the range from 2.4 V to 3.6 V.



6.21 NOR Flash memory device

M29W128GL70ZA6E, a 128-Mbit NOR Flash memory, 8 M x16 bit, is fitted on the STM32L4R9I-EVAL main board, in U11 position. The STM32L4R9I-EVAL main board, as well as the addressing capabilities of FMC, allow hosting M29W256GL70ZA6E, a 256-Mbit NOR Flash memory device. This is the reason why the schematic diagram mentions both devices.

The NOR Flash memory device is attached to the 16-bit data bus and accessed with FMC. The base address is 0x6800 0000, corresponding to NOR/SRAM2 bank1. The NOR Flash memory device is selected with the FMC_NE3 chip select signal. 16-bit data word operation mode is selected by a pull-up resistor connected to the BYTE terminal of NOR Flash memory. The jumper JP6 is dedicated to writing protect configuration.

By default, the FMC_NWAIT signal is not routed to the RB port of the NOR Flash memory device, and, to know its ready status, its status register is polled by the demo software fitted in STM32L4R9I-EVAL. This is modifiable with configuration elements, as shown in [Table 15](#).

Table 15. NOR Flash memory-related jumper

Jumper	Setting	Configuration
JP6		Default setting. NOR Flash memory write is enabled.
		NOR Flash memory write is inhibited. Write protect is activated.

6.21.1 Limitations

The NOR Flash memory device's addressable space is limited if some or all of A21, A22, and A23 FMC address lines are shunted to the CN12 connector for debug trace purposes. In such

a case, the disconnected addressing inputs of the NOR Flash memory device are pulled down by resistors. [Section 6.4](#) provides information on the associated configuration elements.

6.21.2 Operating voltage

NOR Flash memory operating voltage must be in the range from 1.65 V to 3.6 V.

6.22 EEPROM

M24128-DFDW6TP, a 128-Kbit I²C-bus EEPROM device, is fitted on the main board of STM32L4R9I-EVAL, in U3 position. It is accessed with I²C-bus lines I2C2_SCL and I2C2_SDA of STM32L4R9AI16. It supports all I²C-bus modes with speeds up to 1 MHz. The base I²C-bus address is 0xA0. Write-protecting the EEPROM is possible through opening the SB13 solder bridge. By default, SB13 is closed and writing into the EEPROM enabled.

6.22.1 Operating voltage

The M24128-DFDW6TP EEPROM device's operating voltage must be in the range from 1.7 V to 3.6 V.

6.23 EXT_I2C connector

The connection of CN2 EXT_I2C to the I²C bus daughterboard is possible. MFX_GPIO8 of MFX MCU provides the EXT_RSET signal, and the SB12 solder bridge is used to connect the +5 V power supply of the daughterboard.

6.24 Octo-SPI Flash memory device

MX25LM51245GXDI00, a 512-Mbit Octo-SPI Flash memory device, is fitted on the STM32L4R9I-EVAL main board, in U6 position. It allows evaluating STM32L4R9AI16 Octo-SPI interface.

MX25LM51245GXDI00 operates in a single transfer rate (STR) mode or a double transfer rate (DTR) mode.

[Table 16](#) shows the configuration elements and their settings allowing them to access the Octo-SPI Flash memory device.

Table 16. Configuration elements related to Octo-SPI Flash device

Element	Setting	Configuration
R221 R215	R221 in R215 out	Default setting. OctoSPI1_CLK is available to the Octo-SPI Flash memory device.
	R221 out R215 in	OctoSPI1_CLK is not available to the Octo-SPI Flash memory device. PA3 port of STM32L4R9AI16 is routed to the OpAmp1_Vout signal.

Table 16. Configuration elements related to Octo-SPI Flash device (continued)

Element	Setting	Configuration
R67 SB54	R67 in SB54 open	Default setting. OctoSPI1_IO6 data line is available to the Octo-SPI Flash memory device.
	R67 out SB54 closed	OctoSPI1_IO6 is not available to the Octo-SPI Flash memory device. PC3 port of SSTM32L4R9AI16 is routed to the motor-control signal.
R75 SB55	R75 in SB55 open	Default setting. OctoSPI1_IO7 data line is available to the Octo-SPI Flash memory device.
	R75 out SB55 closed	OctoSPI1_IO7 is not available to the Octo-SPI Flash memory device. PC4 port of STM32L4R9AI16 is routed to the motor-control signal.

6.24.1 Limitations

Octo-SPI Flash memory device operation is exclusive with OpAmp1 and with motor control.

6.24.2 Operating voltage

The voltage of Octo-SPI Flash memory device MX25LM51245GXD100 is in the range of 2.7 V to 3.6 V.

6.25 Octo-SPI DRAM device

IS66WVH8M8BLL-100BLI, a 64-Mbit self-refresh dynamic RAM (DRAM) device with a HyperBus interface, is fitted on the STM32L4R9I-EVAL main board, in U5 position. It allows the evaluation of the STM32L4R9AI16 Octo-SPI interface.

6.25.1 Operating voltage

The voltage of the Octo-SPI DRAM device IS66WVH8M8BLL-100BLI is in the range of 2.7 V to 3.6 V.

6.25.2 Limitations

Board does not support Octo-SPI operation with IS66WVH8M8BLL-100BLI. No workaround is available. Please refer to *STM32L4Rxxx and STM32L4Sxxx device errata* (ES0393).

6.26 Touch-sensing button

The STM32L4R9I-EVAL board supports a touch sensing button based on either RC charging or charge-transfer technique. The latter is enabled, by default.

The touch sensing button is connected to the PC6 port of STM32L4R9AI16 and the related charge capacitor is connected to PC7.

An active shield is designed in layer 2 of the main PCB, under the button footprint. It allows reducing disturbances from other circuits to prevent false touch detections.

The active shield is connected to the PB6 port of STM32L4R9AI6 through the resistor R22. The related charge capacitor is connected to PB7.

[Table 17](#) shows the configuration elements related to the touch sensing function. Some of them serve to enable or disable its operation. However, most of them serve to optimize the touch sensing performance, by isolating copper tracks to avoid disturbances due to their antenna effect.

Table 17. Touch-sensing-related configuration elements

Element	Setting	Configuration
R44	In	PC6 port is routed to the CN6 connector of the daughterboard. This setting is not good for the robustness of touch sensing.
	Out	Default setting. PC6 port is cut from CN6.
SB21	Open	Default setting. PC6 is not routed to motor control.
	Closed	PC6 is routed to motor control. This setting is not good for the robustness of touch sensing.
R46	In	PC7 port is routed to the CN6 connector of the daughterboard. This setting is not good for the robustness of touch sensing.
	Out	Default setting. PC7 port is cut from CN6.
SB19	Open	Default setting. PC7 is not routed to motor control.
	Closed	PC7 is routed to motor control. This setting is not good for the robustness of touch sensing.
SB20	Open	PC7 is not routed to the sampling capacitor. Touch sensing cannot operate.
	Closed	Default setting. PC7 is routed to the sampling capacitor. Touch sensing available.
R26	In	PB6 port is routed to the CN5 connector of the daughterboard. This setting is not good for the robustness of touch sensing.
	Out	Default setting. PB6 port is cut from CN5.
SB14	Open	Default setting. PB6 is not routed to motor control.
	Closed	PB6 is routed to motor control. This setting is not good for the robustness of touch sensing.
SB15	Open	PB6 is not routed to the active shield under the touch sensing button. This setting is not good for the robustness of touch sensing.

Table 17. Touch-sensing-related configuration elements (continued)

Element	Setting	Configuration
	Closed	Default setting. PB6 is routed to the active shield under the touch sensing button. This setting is not good for the robustness of touch sensing.
SB16	Open	Default setting. PB6 is not routed to the CN16 DSI display connector.
	Closed	PB6 is routed to the CN16 DSI display connector. This setting is not good for the robustness of touch sensing.
R30	In	PB7 port is routed to the CN5 connector of the daughterboard. This setting is not good for the robustness of touch sensing.
	Out	Default setting. PB7 port is cut from CN5.
SB17	Open	Default setting. PB7 is not routed to motor control.
	Closed	PB7 is routed to motor control. This setting is not good for the robustness of touch sensing.
SB18	Open	PB7 is not routed to the sampling capacitor of the active shield under the touch sensing button. This setting is not good for the robustness of touch sensing.
	Closed	Default setting. PB6 is routed to the sampling capacitor of the active shield under the touch sensing button. This setting is not good for the robustness of touch sensing.

6.26.1 Limitations

The touch-sensing button is exclusive with the DSI display connector, motor control, and daughterboard connector.

6.27 MFX MCU

The MFX MCU is used as MFX (multi-function expander) and IDD measurement.

The MFX circuit on the STM32L4R9I-EVAL board acts as IO-expander. The communication interface between MFX and STM32L4R9AI16 is the I2C2 bus. The signals connected to MFX are listed in [Table 18](#).

Table 18. MFX signals

Pin number of MFX	Pin name of MFX	MFX functions	Function of STM32L4R9AI16	Direction (for MFX)	Terminal device
15	PA5	MFX_GPIO5	uS_Detect	Input	microSD™
16	PA6	MFX_GPIO6	USB_PSON	Output	USB_FS
17	PA7	MFX_GPIO7	USB_OVRCCR	Input	USB_FS

Table 18. MFX signals (continued)



Pin number of MFX	Pin name of MFX	MFX functions	Function of STM32L4R9AI16	Direction (for MFX)	Terminal device
18	PB0	MFX_GPIO0	JOY_SEL	Input	Joystick
19	PB1	MFX_GPIO1	JOY_DOWN	Input	Joystick
20	PB2	MFX_GPIO2	JOY_LEFT	Input	Joystick
26	PB13	MFX_GPIO13	-	-	-
27	PB14	MFX_GPIO14	-	-	-
28	PB15	MFX_GPIO15	-	-	-
29	PA8	MFX_GPIO8	EXT_RESET	Output	EXT_I2C
30	PA9	MFX_GPIO9	DSI_RST	Output	DSI LCD
31	PA10	MFX_GPIO10	-	-	-
32	PA11	MFX_GPIO11	LCD_DISP	Output	TFT LCD
33	PA12	MFX_GPIO12	LCD_RST	Output	TFT LCD
39	PB3	MFX_GPIO3	JOY_RIGHT	Input	Joystick
40	PB4	MFX_GPIO4	JOY_UP	Input	Joystick

6.28 IDD measurement

STM32L4R9AI16 has a built-in circuit allowing to measure its current consumption (IDD) in Run and Low-power modes, except for Shutdown mode. It is strongly recommended that the MCU supply voltage (VDD_MCU line) does not exceed 3.3 V. This is because there are components on STM32L4R9I-EVAL supplied from 3.3 V that communicate with the MCU through I/O ports. Voltage exceeding 3.3 V on the MCU output port may inject current into 3.3 V-supplied peripheral I/Os and false the MCU current consumption measurement.

[Table 19](#) shows the setting of jumpers associated with the IDD measurement on the board.

Table 19. IDD measurement related jumper setting

Jumper	Setting	Configuration
JP4		Default setting. STM32L4R9AI16 has a built-in circuit allowing to measure its current consumption.
		IDD measurement is not available, bypass mode only for STM32L4R9AI16 VDD_MCU power supply.

6.29 DSI display (MIPI) connector

The CN16 connector is designed to connect a DSI display daughterboard. MB1314 daughterboard is available to mount on the STM32L4R9I-EVAL board. [Table 20](#) shows the assignment of CN16 and STM32L4R9AI16 terminals.

Table 20. CN16 DSI display module connector

Pin No.	Description	Pin connection	Pin No.	Description	Pin connection
1	GND	-	2	-	-
3	DSI_CK_P	-	4	DSI_INT	PC2
5	DSI_CK_N	-	6	GND	-
7	GND	-	8	RFU	GND
9	DSI_D0_P	-	10	RFU	GND
11	DSI_D0_N	-	12	GND	-
13	GND	-	14	RFU	GND
15	DSI_D1_P	-	16	RFU	GND
17	DSI_D1_N	-	18	GND	-
19	GND	-	20	-	-
21	BLVDD (5 V)	-	22	SPI_CS	PG12
23	BLVDD (5 V)	-	24	SPI_CLK/UART_CK	PI1/PG13
25	-	-	26	SPI_SDI/UART_TX	PI3/PB6
27	BLGND	-	28	SPI_DCX	PI2
29	BLGND	-	30	-	-
31	-	-	32	-	-
33	-	-	34	-	-
35	SCLK/MCLK	PA8	36	3.3 V	-
37	LRCLK	PB9	38	VDD	-
39	I2S_DATA	PC1	40	I2C_SDA	PH5
41	-	-	42	-	-
43	SWIRE	PG6	44	I2C_SCL	PH4
45	CEC_CLK	NA	46	-	-
47	CEC	NA	48	-	-
49	DSI_TE	PF11	50	-	-
51	-	-	52	-	-
53	DSI_BL_CTRL	PB14	54	-	-
55	-	-	56	-	-
57	DSI_RST	MFx_GPIO9	58	-	-
59	-	-	60	1.8 V	-

6.29.1 Limitations

The DSI display module connector signal INT is used both for TFT LCD and DSI display connector.

6.30 TFT LCD (RGB and FMC mode) connector

The CN20 50-pin 1.27 mm-pitch female connector is designed to connect TFT LCD daughterboard, supporting RGB and FMC modes. MB1315 daughterboard is available to mount on the STM32L4R9I-EVAL board with RGB mode. [Table 21](#) shows the assignment of CN20 and STM32L4R9AI16 terminals.

Table 21. CN20 TFT LCD module connector

Pin No.	RGB mode description	FMC mode description	Pin connection	Pin No.	RGB mode description	FMC mode description	Pin connection
1	GND	GND	-	2	GND	GND	-
3	R0	-	PE2	4	G0	-	PF14
5	R1	RS(A19)	PE3	6	G1	-	PF15
7	R2	D12	PE15	8	G2	D6	PE9
9	R3	D13	PD8	10	G3	D7	PE10
11	R4	D14	PD9	12	G4	D8	PE11
13	R5	D15	PD10	14	G5	D9	PE12
15	R6	-	PD11	16	G6	D10	PE13
17	R7	-	PD12	18	G7	D11	PE14
19	GND	GND	-	20	GND	GND	-
21	B0	-	PE4	22	DE	TE	PF11
23	B1	-	PF13	24	LCD_DSIP	-	MFX_GPIO11
25	B2	D0	PD14	26	HSYNC	-	PE0
27	B3	D1	PD15	28	VSYNC	-	PE1
29	B4	D2	PD0	30	GND	GND	-
31	B5	D3	PD1	32	PCLK	-	PD3
33	B6	D4	PE7	34	GND	GND	-
35	B7	D5	PE8	36	RST#	RST#	MFX_GPIO12
37	GND	GND	-	38	SDA	SDA	PH5
39	INT	INT	PC2	40	SCL	SCL	PH4
41	-	RS	PE2	42	-	NOE	PD4
43	BL_CTRL	BL_CTRL	PA5	44	-	NWE	PD5
45	BL+5 V	BL+5 V	-	46	-	CS	PG12
47	BLGND	BLGND	-	48	VDD	VDD	-
49	BLGND	BLGND	-	50	+3.3 V	+3.3 V	-

6.30.1 Limitations

The TFT LCD module connector supports RGB mode or FMC mode only at the same time. The signal INT is used both for TFT LCD and DSI display connectors. When RGB mode TFT LCD is used, STM32L4R9AI6 cannot access onboard SRAM and NOR Flash memory.

6.31 PMOD connector

The P1 PMOD-standard connector is available on the STM32L4R9I-EVAL board to support flexibility in small form factor applications. The PMOD connector implements the PMOD type 2A and 4A on the STM32L4R9I-EVAL board.

Table 22. P1 PMOD connector

Pin number	Description	Pin number	Description
1	SS/CTS (PI0/PB13)	7	INT (PG13)
2	MOSI/TXD (PI3/PG7)	8	RESET (PB14)
3	MISO/RXD (PI2/PG8)	9	-
4	SCK/RTS (PI1/PB12)	10	-
5	GND	11	GND
6	3.3 V	12	3.3 V

6.32 MB1314 DSI display board

MB1314 is the DSI display daughterboard that is available to mount on the STM32L4R9I-EVAL board via CN1 connector. GVO IEG1120TB103GF-001 is selected for round LCD with one data lane, 390x390 resolution, 24 bpp with capacitive touch panel (FocalTech FT3x67 driver). [Table 23](#) shows the pin function description of the CN1 MB1314 board connector.

Table 23. Pin function description of the CN1 MB1314 board connector

Pin number	Description	Pin number	Description
1	GND	2	-
3	DSI_CK_P	4	DSI_INT
5	DSI_CK_N	6	GND
7	GND	8	RFU
9	DSI_D0_P	10	RFU
11	DSI_D0_N	12	GND
13	GND	14	RFU
15	RFU	16	RFU
17	RFU	18	GND
19	GND	20	-
21	BLVDD (5 V)	22	RFU

Table 23. Pin function description of the CN1 MB1314 board connector (continued)

Pin number	Description	Pin number	Description
23	BLVDD (5 V)	24	RFU
25	-	26	RFU
27	BLGND	28	RFU
29	BLGND	30	-
31	-	32	-
33	-	34	-
35	RFU	36	3.3 V
37	RFU	38	VDD
39	RFU	40	I2C_SDA
41	-	42	-
43	SWIRE	44	I2C_SCL
45	RFU	46	-
47	RFU	48	-
49	DSI_TE	50	-
51	-	52	-
53	DSI_BL_CTRL	54	-
55	-	56	-
57	DSI_RST	58	-
59	-	60	RFU

Warning: Permanent Image sticking may occur if AMOLED displays the same image for an extended time.

6.33 MB1315 TFT LCD board

MB1315 is the TFT LCD daughterboard supporting RGB mode, available to mount on the STM32L4R9I-EVAL board via CN1 connector.

The 4.3" TFT LCD uses LCD RK043FN48H-CT672B with a capacitive touch panel which only supports 3.3 V power and interface. So a level shifter SN74LVC16T245DGGR is requested on TFT RGB LCD daughterboard to support a wide power supply range. [Table 24](#) shows the pin function description of the CN1 MB1315 board connector.

Table 24. Pin function description of the CN1 MB1315 board connector

Pin number	Description	Pin number	Description
1	GND	2	GND
3	R0	4	G0
5	R1	6	G1
7	R2	8	G2
9	R3	10	G3
11	R4	12	G4
13	R5	14	G5
15	R6	16	G6
17	R7	18	G7
19	GND	20	GND
21	B0	22	DE
23	B1	24	LCD_DSIP
25	B2	26	HSYNC
27	B3	28	VSYNC
29	B4	30	GND
31	B5	32	PCLK
33	B6	34	GND
35	B7	36	RST#
37	GND	38	SDA
39	INT	40	SCL
41	-	42	-
43	BL_CTRL	44	-
45	BL+5 V	46	-
47	BLGND	48	VDD
49	BLGND	50	+3.3 V

7 Connectors

7.1 CN1 motor-control connector

Figure 11. CN1 motor-control connector (top view)




Table 25. CN1 motor-control connector

Description	Pin of STM32L4R9AI16	Pin number of CN1	Pin number of CN1	Pin of STM32L4R9AI16	Description
Emergency STOP	PI4	1	2	-	GND
PWM_1H	PC6	3	4	-	GND
PWM_1L	PH13	5	6	-	GND
PWM_2H	PC7	7	8	-	GND
PWM_2L	PH14	9	10	-	GND
PWM_3H	PC8	11	12	-	GND
PWM_3L	PH15	13	14	PC4	BUS VOLTAGE
CURRENT A	PC0	15	16	-	GND
CURRENT B	PC1	17	18	-	GND
CURRENT C	PC2	19	20	-	GND
ICL Shutout	PG9	21	22	-	GND
DISSIPATIVE BRAKE	PG13	23	24	PA0	PCD Ind. Current
+5 V power	-	25	26	PA1	Heatsink temperature
PFC SYNC	PB14	27	28	-	3.3 V power
PFC PWM	PB15	29	30	PA9	PFC Shut Down
Encoder A	PB6	31	32	PC3	PFC Vac
Encoder B	PB7	33	34	PB8	Encoder Index

7.2 CN2 external I²C connector

Figure 12. CN2 EXT_I2C connector (front view)




Table 26. CN2 EXT_I2C connector

Pin number	Description	Pin number	Description
1	I2C1_SDA (PH5)	5	VDD
2	NC	6	NC
3	I2C1_SCL (PH4)	7	GND
4	EXT_RESET (MFX_GPIO8)	8	NC

7.3 CN3 USB OTG FS Micro-AB connector

Figure 13. CN3 USB OTG FS Micro-AB connector (front view)




Table 27. CN3 USB OTG FS Micro-AB connector

Pin number	Description	Pin number	Description
1	V _{BUS} (PA9)	4	ID (PA10)
2	DM (PA11)	5	GND
3	DP (PA12)	-	-

7.4 CN4 analog input-output connector

Figure 14. CN4 analog input-output connector (top view)




Table 28. CN4 analog input-output connector

Pin number	Description	Pin number	Description
1	GND	2	Analog input-output PA4

7.5 CN5, CN6, CN13, and CN14 extension connectors

All GPIO signals from STM32L4R9AI16 are connected to CN5, CN6, CN13, and CN14 extension connectors. CN13 and CN14 extension connectors are also used for the FMC device.

Table 29. CN5 daughterboard extension connector

Pin number	Description	Alternative functions	How to disconnect alternative functions to use on the extension connector
1	PH9	OCTO-SPI2_IO4	Remove U5.
3	PH14	LED3, MC	Remove R185, open SB44.
5	PH15	LED4, MC	Remove R184, open SB45.
7	PI3	SPI2_MOSI	No connection for CN16 and P1
9	GND	-	-
11	PH13	LED2, MC	Remove R186, open SB46.
13	PG13	PMOD_INT, USART1_CK, MC	Open SB29, SB47. No connection for P1
15	PB5	SAI1_SDB, Comp2_OUT	Remove R204, open SB48.
17	PI9	OCTO-SPI2_IO2	Remove U5.
19	PI11	OCTO-SPI2_IO0	Remove U5.
21	NC	-	-
23	PC14	OSC32_IN	Remove R50, close SB50.
25	PC13	Wakeup	Remove R188.
27	PH1	OSC_OUT	Remove R65, close SB53.
29	GND	-	-
31	PA5	TFT LCD_BL_CTRL	No connection for CN20
33	PC2	DSI LCD_INT, TFT LCD_INT, MC	Remove R217, open SB43.

Table 29. CN5 daughterboard extension connector (continued)

Pin number	Description	Alternative functions	How to disconnect alternative functions to use on the extension connector
35	PH8	OCTO-SPI2_IO3	Remove U5.
37	PH10	OCTO-SPI2_IO5	Remove U5.
39	D5V	-	-
2	PI5	OCTO-SPI2_NCS	Remove U5.
4	PH12	OCTO-SPI2_IO7	Remove U5.
6	PI6	OCTO-SPI2_CLK	Remove U5.
8	PG15	OCTO-SPI2_DQS	Remove U5.
10	GND	-	-
12	PB4	Comp2_INP, TRST	Remove R200, open SB22.
14	PB6	TS_SHIELD, USART1_TX, MC	Closed R26, open SB14, SB16, and SB15.
16	PB7	TS_SHIELD_CS, MC	Closed R30, open SB17 and SB18.
18	PI10	OCTO-SPI2_IO1	Remove U5.
20	PI7	-	-
22	PH3	BOOT0	Remove R1.
24	PC15	OSC32_OUT	Remove R49, close SB49.
26	PH0	OSC_IN	Remove R61, close SB52.
28	PA0	MFx_IRQ_OUT, OpAmp1_INP, MC	Remove R214, open SB38 and SB39.
30	GND	-	-
32	PA1	OpAmp1_INM, MC	Remove R216, open SB40.
34	PA4	ADC_DAC	Remove R32.
36	PH11	OCTO-SPI2_IO6	Remove U5.
38	VDD	-	-
40	+3V3	-	-

Table 30. CN6 daughterboard extension connector

Pin number	Description	Alternative functions	How to disconnect alternative functions to use on the extension connector
1	PH2	OCTO-SPI1_IO4	Remove U6.
3	PI0	SPI2_NSS	No connection for P1
5	PD2	SDIO1_CMD	Remove R55, no SD card insert.
7	PI1	SPI2_SCK	No connection for CN16 and P1
9	GND	-	-
11	PA12	USB OTG_DP	No connection for CN3

Table 30. CN6 daughterboard extension connector (continued)

Pin number	Description	Alternative functions	How to disconnect alternative functions to use on the extension connector
13	PA11	USB OTG_DM	No connection for CN3
15	PG8	LPUART1_RX	Remove U9.
17	PA9	VBUS_FS, MC	Remove R203, open SB35.
19	PC9	SDIO1_D1, Trace_D0	Remove R205, open SB57.
21	PC7	TS_KEY_CS, MC	Closed R46, open SB19 and SB20.
23	PB15	LED1, MC	Remove R187, open SB51.
25	PB13	LPUART1_CTS	Remove U9.
27	RESET#	-	-
29	GND	-	-
31	PA3	OpAmp1_VOUT, OCTO-SPI1_CLK	Remove R221, R215.
33	PA7	OCTO-SPI1_IO2	Remove U6.
35	PC4	OCTO-SPI1_IO7, MC	Remove R75, open SB55.
37	PC3	OCTO-SPI1_IO6, MC	Remove R67, open SB54.
39	D5V	-	-
2	PG11	OCTO-SPI1_IO5	Remove U6.
4	PI2	SPI2_MISO	No connection for CN16 and P1
6	PC8	SDIO1_D0, MC	Remove R195, open SB2.
8	PC10	SDIO1_D2, Trace_D1	Remove R197, open SB58.
10	GND	-	-
12	PC11	SDIO1_D3	Remove R60, no SD card insert.
14	PC12	SDIO1_CLK	no SD card insert.
16	PA10	USB OTG_ID	No connection for CN3
18	PC6	TS_KEY, MC	Closed R44, open SB21.
20	PG7	LPUART1_TX	Remove R19 and U1.
22	PB14	DSI LCD_BL_CTRL, PMOD_RST, MC	Remove R207, open SB41. No connection for P1
24	PB12	LPUART1_RTS	Remove R5 and U1.
26	PF11	DSI LCD_TE, TFT LCD_DE	No connection for CN16 and CN20
28	PB0	OCTO-SPI1_IO1	Remove U6.
30	GND	-	-
32	PB1	OCTO-SPI1_IO0	Remove U6.
34	PB2	OCTO-SPI1_DQS	Remove U6.
36	PA6	OCTO-SPI1_IO3	Remove U6.

Table 30. CN6 daughterboard extension connector (continued)

Pin number	Description	Alternative functions	How to disconnect alternative functions to use on the extension connector
38	PA2	OCTO-SPI1_NCS	Remove U6.
40	+5V	-	-

Table 31. CN13 daughterboard extension connector

Pin number	Description	Alternative functions	How to disconnect alternative functions to use on the extension connector
1	PD1	FMC_D3	-
3	PD0	FMC_D2	-
5	PB8	SAI1_MCLKA, CAN_RX, MC	Remove R235, open SB42 and JP12.
7	PG10	FMC_NE3	-
9	GND	-	-
11	PE0	FMC_NBL0	-
13	PG12	FMC_NE4, SPI	Remove R238, open SB26.
15	PE4	FMC_A20	-
17	PE5	FMC_A21	Keep CN12 open.
19	PF1	FMC_A1	-
21	PF2	FMC_A2	-
23	PB9	SAI1_FSA, CAN_TX	Remove R243, R247.
25	PF10	DFSDM_CLK	Open JP16.
27	PF5	FMC_A5	-
29	GND	-	-
31	PF4	FMC_A4	-
33	PF15	FMC_A9	-
35	PG0	FMC_A10	-
37	PE10	FMC_D7	-
39	VDD	-	-
2	NC	-	-
4	PD6	FMC_NWAIT	-
6	PD4	FMC_NOE	-
8	PE1	FMC_NBL1	-
10	GND	-	-
12	PD5	FMC_NWE	-
14	PE2	FMC_A23	Keep CN12 open.
16	PE3	FMC_A19	-

Table 31. CN13 daughterboard extension connector (continued)

Pin number	Description	Alternative functions	How to disconnect alternative functions to use on the extension connector
18	PE6	FMC_A22	Keep CN12 open.
20	PF0	FMC_A0	-
22	PC0	DFSDM, MC	Remove R242, open SB36.
24	PC1	SAI1, MC	Remove R244, open SB37.
26	PF3	FMC_A3	-
28	PG4	FMC_A14	-
30	GND	-	-
32	PG1	FMC_A11	-
34	PF12	FMC_A6	-
36	PF13	FMC_A7	-
38	PF14	FMC_A8	-
40	+3V3	-	-

Table 32. CN14 daughterboard extension connector

Pin number	Description	Alternative functions	How to disconnect alternative functions to use on the extension connector
1	PA14	JTAG_TCK/SWCLK	Do not use CN11, CN12, CN15, and CN17 for debug connector.
3	PD7	FMC_NE1	-
5	PD3	TFT LCD_CLK	No connection for CN20
7	PB3	JTAG_TDO/SWO	Do not use CN11, CN12, CN15, and CN17 for debug connector.
9	GND	-	-
11	PG5	FMC_A15	-
13	PD15	FMC_D1	-
15	PD14	FMC_D0	-
17	PD10	FMC_D15	-
19	PH5	I2C2_SDA	Remove R2.
21	PB10	UART3_TX	Remove R173. No connection for CN11
23	PD8	FMC_D13	-
25	PD13	FMC_A18	-
27	PE12	FMC_D9	-
29	GND	-	-
31	NC	-	-

Table 32. CN14 daughterboard extension connector (continued)

Pin number	Description	Alternative functions	How to disconnect alternative functions to use on the extension connector
33	PE7	FMC_D4	-
35	PE14	FMC_D11	-
37	PE15	FMC_D12	-
39	VDD	-	-
2	PA13	JTAG_TMS/SWDIO	Do not use CN11, CN12, CN15, and CN17 for debug connector.
4	PA15	JTAG_TDI	Do not use CN11, CN12, CN15, and CN17 for debug connector.
6	PI4	Audio_INT, MC	Remove R234, open SB3.
8	PG9	MFx_WAKUP, MC	Remove R236, open SB34.
10	GND	-	-
12	PA8	SAI1_SCKA	Remove U26.
14	PG3	FMC_A13	-
16	PG6	DSI_LCD_SWIRE	No connection for CN16
18	PG2	FMC_A12	-
20	PD11	FMC_A16	-
22	PH4	I2C2_SCL	Remove R3.
24	PB11	UART3_RX	Remove R171. No connection for CN11
26	PD9	FMC_D14	-
28	PD12	FMC_A17	-
30	GND	-	-
32	PE13	FMC_D10	-
34	PE8	FMC_D5	-
36	PE11	FMC_D8	-
38	PE9	FMC_D6	-
40	+3V3	-	-

7.6 CN7 RS232 connector

Figure 15. RS232 D-sub male connector (front view)




Table 33. RS232 D-sub male connector

Pin number	Description	Pin number	Description
1	NC	6	NC
2	RS232_RX (PG8)	7	RS232_RTS (PB12)
3	RS232_TX (PG7)	8	RS232_CTS (PB13)
4	NC	9	NC
5	GND	-	-

7.7 CN8 microSD™ connector

Figure 16. CN8 microSD™ connector (top view)




Table 34. CN8 microSD™ connector

Pin number	Description	Pin number	Description
1	SDIO_D2 (PC10)	6	Vss/GND
2	SDIO_D3 (PC11)	7	SDIO_D0 (PC8)
3	SDIO_CMD (PD2)	8	SDIO_D1 (PC9)
4	VDD	9	GND
5	SDIO_CLK (PC12)	10	MicroSDcard_detect (MFX GPIO15)

7.8 CN9 MFX programming connector

The CN9 connector is used only for embedded MFX (multi-function expander) programming during board manufacture. It is not populated by default and not for the end-user.

7.9 CN11 STDC14 connector

Figure 17. CN11 STDC14 debugging connector (top view)




Table 35. CN11 STDC14 debugging connector

Terminal	Function / MCU port	Terminal	Function / MCU port
1	-	2	-
3	VDD	4	SWDIO/TMS (PA13)
5	GND	6	SWDCLK/TCK (PA14)
7	GND	8	SWO/TDO (PB3)
9	KEY	10	TDI (PA15)
11	GND	12	RESET#
13	VCP_RX (PB11) ⁽¹⁾	14	VCP_TX (PB10) ⁽¹⁾

1. Due to discrepancies between the port terminal and sheet symbol, VCP_RX and VCP_TX are not connected to MCU

7.10 CN12 trace debugging connector

Figure 18. CN12 ETM trace debugging connector (top view)




Table 36. CN12 trace debugging connector

Pin number	Description	Pin number	Description
1	+3.3 V	2	TMS/PA13
3	GND	4	TCK/PA14
5	GND	6	TDO/PB3
7	KEY	8	TDI/PA15
9	GND	10	RESET#
11	GND	12	Trace_CLK/PE2
13	GND	14	Trace_D0/PC9 or SWO/PB3
15	GND	16	Trace_D1/PC10 or nTRST/PB4
17	GND	18	Trace_D2/PE5
19	GND	20	Trace_D3/PE6

7.11 CN15 TAG connector

Table 37. CN15 TAG debugging connector

Terminal	Function / MCU port	Terminal	Function / MCU port
1	VDD	2	SWDIO/TMS (PA13)
3	GND	4	SWDCLK/TCK (PA14)
5	GND	6	SWO/TDO (PB3)
7	NC	8	TDI (PA15)
9	TRST (PB4)	10	RESET#

7.12 CN16 DSI display connector (MIPI)

A TFT color LCD with the MIPI DSISM interface board is mounted on CN16. Refer to [Section 6.29](#) for detail.

7.13 CN17 JTAG connector

Figure 19. CN17 JTAG/SWD debugging connector (top view)





Table 38. CN17 JTAG/SWD debugging connector

Pin number	Description	Pin number	Description
1	VDD power	2	VDD power
3	PB4	4	GND
5	PA15	6	GND
7	PA13	8	GND
9	PA14	10	GND
11	NC	12	GND
13	PB3	14	GND
15	RESET#	16	GND
17	-	18	GND
19	-	20	GND

7.14 CN18 power connector

The STM32L4R9I-EVAL board is power-able with a DC 5 V power supply via the external power supply jack (CN18) shown in [Figure 20](#). The central pin of CN18 must be positive.

Figure 20. CN18 power-supply connector (front view)



7.15 CN19 ST-LINK/V2-1 programming connector

The CN19 connector is used only for embedded ST-LINK/V2-1 programming during board manufacturing. It is not populated by default and not for end-users.

7.16 CN20 TFT LCD connector (RGB)

A TFT-color LCD board is mounted on CN20. Refer to [Section 6.30](#) for details.

7.17 CN21 ST-LINK/V2-1 USB Micro-B connector

The CN21 USB connector is used to connect on-board ST-LINK/V2-1 facility to a PC for programming and debugging purposes.

Figure 21. CN21 USB Micro-B connector (front view)




Table 39. CN21 USB Micro-B connector (front view)

Pin number	Description	Pin number	Description
1	V _{BUS} (power)	4	GND

Table 39. CN21 USB Micro-B connector (front view) (continued)

Pin number	Description	Pin number	Description
2	DM	5	Shield
3	DP	-	-

7.18 CN22 CAN D-type male connector

Figure 22. CN22 CAN D-type 9-pin male connector (front view)




Table 40. CN22 CAN D-type 9-pin male connector

Pin number	Description	Pin number	Description
1,4,8,9	NC	7	CANH
2	CANL	3,5,6	GND

Appendix A I/O assignment

Table 41. STM32L4R9I-EVAL I/O assignment

Primary key	UFBGA 169 DSI	Pin name	Pinout assignment	RGB LCD with FMC mode	Motor-control connector
1	K12	DSI_CKN	-	-	-
2	K11	DSI_CKP	-	-	-
3	L12	DSI_D0N	-	-	-
4	L11	DSI_D0P	-	-	-
5	J12	DSI_D1N	-	-	-
6	J11	DSI_D1P	-	-	-
7	L13	VCAPDSI	-	-	-
8	[L13]	VDD12DSI	-	-	-
9	[L13]	VDD12DSI	-	-	-
10	J13	VSSDSI	-	-	-
11	K13	VSSDSI	-	-	-
12	H3	NRST	NRST	-	-
13	K3	PA0	OPAMP1_VINP MFX_IRQ_OUT	-	PFC indirect current
14	M1	PA1	OPAMP1_VINM	-	Heatsink Temp.
15	N1	PA2	OCTOSPIP1_NCS	-	-
16	M2	PA3	OCTOSPIP1_CLK OPAMP1_VOUT	-	-
17	N2	PA4	ADC/DAC	-	-
18	L3	PA5	LCD_BL_CTRL	-	-
19	L4	PA6	OCTOSPIP1_IO3	-	-
20	M4	PA7	OCTOSPIP1_IO2	-	-
21	E11	PA8	SAI1_SCK_A	-	-
22	E12	PA9	OTG_FS_VBUS	-	PFC shutdown
23	D11	PA10	OTG_FS_ID	-	-
24	E13	PA11	OTG_FS_DM	-	-
25	D13	PA12	OTG_FS_DP	-	-
26	A11	PA13	JTMS/SWDIO	-	-
27	A10	PA14	JTCK/SWCLK	-	-
28	A9	PA15	JTDI	-	-
29	N4	PB0	OCTOSPIP1_IO1	-	-
30	L5	PB1	OCTOSPIP1_IO0	-	-
31	N5	PB2	OCTOSPIP1_DQS	-	-

Table 41. STM32L4R9I-EVAL I/O assignment (continued)

Primary key	UFBGA 169 DSI	Pin name	Pinout assignment	RGB LCD with FMC mode	Motor-control connector
32	A6	PB3	JTDO/TRACESWO	-	-
33	A5	PB4	NJTRST COMP2_INP	-	-
34	B5	PB5	SAI1_SD_B COMP2_OUT	-	-
35	C5	PB6	TSC_G2_IO3 USART1_TX	-	Encoder A
36	D5	PB7	TSC_G2_IO4	-	Encoder B
37	C4	PB8	SAI1_MCLK_A CAN1_RX	-	Encoder Index
38	D4	PB9	SAI1_FS_A CAN1_TX	-	-
39	N9	PB10	UART3_TX	-	-
40	H7	PB11	UART3_RX	-	-
41	N12	PB12	LPUART1_RTS_DE	-	-
42	N13	PB13	LPUART1_CTS	-	-
43	M12	PB14	PMOD_RST/DSI_BL_CTRL	-	PFC sync
44	L10	PB15	LED1	-	PFC PWM
45	J2	PC0	DFSDM1_DATIN4	-	PhaseA Current+
46	J3	PC1	SAI1_SD_A	-	PhaseB Current+
47	J4	PC2	LCD_INT	-	PhaseC Current+
48	K1	PC3	OCTOSPI1_IO6	-	PFC Vac
49	K4	PC4	OCTOSPI1_IO7	-	Bus Voltage
50	F11	PC6	TSC_G4_IO1	-	MC_PWM_1H
51	G11	PC7	TSC_G4_IO2	-	MC_PWM_2H
52	F9	PC8	uSD1_D0	-	MC_PWM_3H
53	G13	PC9	uSD1_D1 TRACED0	-	-
54	D9	PC10	uSD1_D2 TRACED1	-	-
55	E9	PC11	uSD1_D3	-	-
56	F8	PC12	uSD1_CK	-	-
57	E1	PC13	TAMP1/WKUP2	-	-
58	F1	PC14- OSC32_IN	OSC32_IN	-	-
59	G1	PC15- OSC32_OUT	OSC32_OUT	-	-
60	B8	PD0	FMC_D2	LCD_B4	-
61	C8	PD1	FMC_D3	LCD_B5	-
62	D8	PD2	uSD1_CMD	-	-
63	E8	PD3	-	LCD_CLK	-
64	C7	PD4	FMC_NOE	LCD_NOE	-

Table 41. STM32L4R9I-EVAL I/O assignment (continued)

Primary key	UFBGA 169 DSI	Pin name	Pinout assignment	RGB LCD with FMC mode	Motor-control connector
65	D7	PD5	FMC_NWE	LCD_NWE	-
66	E7	PD6	FMC_NWAIT	LCD_DE	-
67	F7	PD7	FMC_NE1	-	-
68	K10	PD8	FMC_D13	LCD_R3	-
69	K9	PD9	FMC_D14	LCD_R4	-
70	J10	PD10	FMC_D15	LCD_R5	-
71	J9	PD11	FMC_A16	LCD_R6	-
72	J8	PD12	FMC_A17	LCD_R7	-
73	H8	PD13	FMC_A18	-	-
74	H11	PD14	FMC_D0	LCD_B2	-
75	H10	PD15	FMC_D1	LCD_B3	-
76	A4	PE0	FMC_NBL0	LCD_HSYNC	-
77	B4	PE1	FMC_NBL1	LCD_VSYNC	-
78	D3	PE2	FMC_A23 TRACECK	LCD_R0	-
79	D2	PE3	FMC_A19	LCD_R1	-
80	D1	PE4	FMC_A20	LCD_B0	-
81	E4	PE5	FMC_A21 TRACED2	-	-
82	E3	PE6	FMC_A22 TRACED3	-	-
83	L7	PE7	FMC_D4	LCD_B6	-
84	K6	PE8	FMC_D5	LCD_B7	-
85	J6	PE9	FMC_D6	LCD_G2	-
86	H6	PE10	FMC_D7	LCD_G3	-
87	N8	PE11	FMC_D8	LCD_G4	-
88	M8	PE12	FMC_D9	LCD_G5	-
89	L8	PE13	FMC_D10	LCD_G6	-
90	K7	PE14	FMC_D11	LCD_G7	-
91	J7	PE15	FMC_D12	LCD_R2	-
92	F5	PF0	FMC_A0	-	-
93	F4	PF1	FMC_A1	-	-
94	F3	PF2	FMC_A2	-	-
95	G3	PF3	FMC_A3	-	-
96	G4	PF4	FMC_A4	-	-
97	G5	PF5	FMC_A5	-	-
98	H4	PF10	DFSDM1_CKOUT	-	-

Table 41. STM32L4R9I-EVAL I/O assignment (continued)

Primary key	UFBGA 169 DSI	Pin name	Pinout assignment	RGB LCD with FMC mode	Motor-control connector
99	M5	PF11	DSI_TE/LCD_DE	-	-
100	N6	PF12	FMC_A6	-	-
101	M6	PF13	FMC_A7	LCD_B1	-
102	L6	PF14	FMC_A8	LCD_G0	-
103	K5	PF15	FMC_A9	LCD_G1	-
104	J5	PG0	FMC_A10	-	-
105	H5	PG1	FMC_A11	-	-
106	H9	PG2	FMC_A12	-	-
107	G8	PG3	FMC_A13	-	-
108	G7	PG4	FMC_A14	-	-
109	G9	PG5	FMC_A15	-	-
110	G12	PG6	SWIRE	-	-
111	G10	PG7	LPUART1_TX	-	-
112	F10	PG8	LPUART1_RX	-	-
113	B7	PG9	MX_WAKEUP	-	ICL shutout
114	D6	PG10	FMC_NE3	-	-
115	E6	PG11	OCTOSPI1_IO5	-	-
116	F6	PG12	SPI_CS	LCD_NE4	-
117	G6	PG13	PMOD_INT/ USART1_CK	-	Dissipative Brake
118	C6	PG15	OCTOSPI2_DQS	-	-
119	H1	PH0-OSC_IN	OSC_IN	-	-
120	J1	PH1-OSC_OUT	OSC_OUT	-	-
121	A2	PH2	OCTOSPI1_IO4	-	-
122	E5	PH3-BOOT0	-	-	-
123	K8	PH4	I2C2_SCL	-	-
124	L9	PH5	I2C2_SDA	-	-
125	N10	PH8	OCTOSPI2_IO3	-	-
126	C11	PH9	OCTOSPI2_IO4	-	-
127	M9	PH10	OCTOSPI2_IO5	-	-
128	M10	PH11	OCTOSPI2_IO6	-	-
129	B13	PH12	OCTOSPI2_IO7	-	-
130	C9	PH13	LED2	-	MC_PWM_1L
131	A13	PH14	LED3	-	MC_PWM_2L
132	B12	PH15	LED4	-	MC_PWM_3L

Table 41. STM32L4R9I-EVAL I/O assignment (continued)

Primary key	UFBGA 169 DSI	Pin name	Pinout assignment	RGB LCD with FMC mode	Motor-control connector
133	A12	PI0	SPI2_NSS	-	-
134	B11	PI1	SPI2_SCK	-	-
135	B10	PI2	SPI2_MISO	-	-
136	C10	PI3	SPI2_MOSI	-	-
137	D10	PI4	Audio_INT	-	MC_EmergencySTOP
138	E10	PI5	OCTOSPI2_NCS	-	-
139	B9	PI6	OCTOSPI2_CLK	-	-
140	B2	PI7	-	-	-
141	B1	PI9	OCTOSPI2_IO2	-	-
142	A1	PI10	OCTOSPI2_IO1	-	-
143	C3	PI11	OCTOSPI2_IO0	-	-
144	E2	VBAT	-	-	-
145	N11	VDD	-	-	-
146	H13	VDD	-	-	-
147	C1	VDD	-	-	-
148	A3	VDD	-	-	-
149	C13	VDD	-	-	-
150	N3	VDD	-	-	-
151	G2	VDD	-	-	-
152	N7	VDD	-	-	-
153	A8	VDD	-	-	-
154	M13	VDDDSI	-	-	-
155	L2	VDDA	-	-	-
156	F12	VDDIO2	-	-	-
157	B6	VDDIO2	-	-	-
158	D12	VDDUSB	-	-	-
159	L1	VREF+	-	-	-
160	K2	VREF-	-	-	-
161	A7	VSS	-	-	-
162	C2	VSS	-	-	-
163	H12	VSS	-	-	-
164	M11	VSS	-	-	-
165	B3	VSS	-	-	-

Table 41. STM32L4R9I-EVAL I/O assignment (continued)

Primary key	UFBGA 169 DSI	Pin name	Pinout assignment	RGB LCD with FMC mode	Motor-control connector
166	C12	VSS	-	-	-
167	H2	VSS	-	-	-
168	F2	VSS	-	-	-
169	M7	VSS	-	-	-
170	M3	VSS	-	-	-
171	F13	VSS	-	-	-

8 STM32L4R9I-EVAL board information

8.1 Product marking

The sticker located on the top or bottom side of the PCB board shows the information about product identification such as board reference, revision, and serial number.

The first identification line has the following format: 'MBxxxx-Variant-yyz', where 'MBxxxx' is the board reference, 'Variant' (optional) identifies the mounting variant when several exist, 'y' is the PCB revision and 'zz' is the assembly revision: for example B01.

The second identification line is the board serial number used for traceability.

Evaluation tools marked as "ES" or "E" are not yet qualified and therefore not ready to be used as reference design or in production. Any consequences deriving from such usage will not be at ST charge. In no event, ST will be liable for any customer usage of these engineering sample tools as reference design or in production.

'E' or 'ES' marking examples of location:

- On the target STM32 that is soldered on the board (for illustration of STM32 marking, refer to the STM32 datasheet "Package information" paragraph at the www.st.com website).
- Next to the evaluation tool ordering part number that is stuck or silk-screen printed on the board.

Some boards feature a specific STM32 device version that allows the operation of any stack or library. This STM32 device shows a 'U' marking option at the end of the standard part number and is not available for sales.

In order to use the same commercial stack in his application, a developer may need to purchase a part number specific to this stack/library. The price of those part numbers includes the stack/library royalties.

The board reference for the STM32L4R9I-EVAL Evaluation board is MB1313, MB1314 for the DSI display daughterboard, and MB1315 for the TFT LCD daughterboard.

8.2 Board revision history

MB1313

Revision B01

The revision B-01 is the initial release.

MB1314

Revision B01

The revision B-01 is the initial release.

Revision C01

CN2 changed to BM20B(0.8)-24DS-0.4V(51)

MB1315

Revision A01

The revision A-01 is the initial release.

8.3 Board known limitations

MB1313

Revision B01

None

MB1314

Revision C01

ZZ1 update to IEG1120TB105GG-001 with a different connector

MB1315

Revision A01

None

Revision history

Table 42. Document revision history

Date	Revision	Changes
18-Aug-2017	1	Initial version
25-Oct-2017	2	<p>Added:</p> <p>STM32L4R9I-EVAL board bottom view in Figure 5 Bootloader limitation in Chapter 9.8.1 Warning on AMOLED display in Chapter 9.32</p> <p>Updated:</p> <p>Cover views Figure 3 and Figure 4 moved to Section 9.1 Table 27 and Table 39 alternative function removed Figure 23, Figure 24, and Figure 37 in <i>Electrical schematics</i></p>
9-Jan-2018	3	<p>Updated:</p> <p>Section 9.8.1: WA3 simplified Table 34: PE3 replaced by PC9, PE4 replaced by PC10</p>
9-Sep-2020	4	<p>Reorganized the entire document:</p> <ul style="list-style-type: none"> – Updated Features, Ordering information, Development environment, Development toolchains, and Demonstration software – Added Codification, Section 6.25.2: Limitations, and Section 8: STM32L4R9I-EVAL board information – Removed Electrical schematics

IMPORTANT NOTICE – PLEASE READ CAREFULLY

STMicroelectronics NV and its subsidiaries (“ST”) reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST’s terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers’ products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. For additional information about ST trademarks, please refer to www.st.com/trademarks. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2020 STMicroelectronics – All rights reserved