

DEVKIT-MPC5748G QUICK START GUIDE (QSG)

Ultra-Reliable MCUs for Industrial and Automotive Applications

www.nxp.com/DEVKIT-MPC5748G



EXTERNAL USE



SECURE CONNECTIONS
FOR A SMARTER WORLD

Contents

- [Quick Start Package Overview](#)
- [Step-by-Step Installation Instructions](#)
- [Hardware: DEVKIT-MPC5748G Board](#)
 - [Features](#)
 - [Overview](#)
 - [Pinout, Jumper and Peripherals Settings](#)
- [Software:](#)
 - [Software Development Tools](#)
 - [Pre-compiled Code Examples](#)
- [Documentation](#)
- [MPC574xG/C/B/D Family : Phantom Feature Differences](#)
- [OpenSDA](#)
- [Recommendations](#)



Quick Start Package Overview

Board:

DEVKIT-MPC5748G	Low cost EVB with MPC5748G(176 LQFP-EP) Auto quality MCU on board
-----------------	---

Documents:

Name	Description
Quick Start Guide(QSG)	Detailed description on availability of Hardware, Software and Documents to quick start with MPC5748G project (this document)
Software Integration Guide(SWIG)	Detailed walk through on how to install and use S32 Design Studio IDE for Power Architecture
Application Notes	Detailed documents covering topics from 'how to design hardware' to 'how to write software'
Fact Sheets, Reference Manuals and Data Sheets	Detailed manuals for MPC5748G family of MCU and DEVKIT-MPC5748G board



Downloads:

Name	Description
Integrated Development Environment (IDE)	Eclipse based S32DS IDE with free GCC compiler and Debugger support
DEVKIT-MPC5748G Quick Start Package	All in one package: Software examples and supporting documents for getting started
DEVKIT-MPC5748G Schematics	PDF schematic files for the DEVKIT-MPC5748G board
DEVKIT-MPC5748G PCB Design Package	Gerber files and Bill of Material



Step-by-Step Installation Instructions

In this quick start guide, you will learn how to set up the **DEVKIT-MPC5748G** board and run the default program.



Jumper Setting:
2-3: USB powered
5V Supply, through
OpenSDA interface

1

Install Software and Tools

Install S32 Design Studio IDE for Power Architecture.
[S32 Design Studio for Power](#)
See Software Installation Guide (SWIG) for detailed procedure

2

Connect the USB Cable

Connect one end of the USB cable to the PC and the other end to the micro-B connector on the DEVKIT-MPC5748G board. Allow the PC to automatically configure the USB drivers.

3

Observe the Default Program reaction

The pre-loaded example project utilizes the **DEVKIT-MPC5748G** user push button (SW2) and the user LEDs. Once the board is plugged in, LEDs will blink in default pattern. Press push button to switch between the two different patterns. Use Potentiometer to change blinking speed. (Clock is configured to PLL running at 160 MHz)


4

Learn More About the DEVKIT-MPC5748G

Read release notes and documentation on the
nxp.com/DEVKIT-MPC5748G
nxp.com/MPC5748G

DEVKIT-MPC5748G Board : Features

- MPC5748G has 2 x 160 MHz Power Architecture® e200Z4 Dual issue cores and 1 x 80 MHz Power Architecture® e200Z2 Single issue core
- MPC5748G qualified to AEC-Q100 Grade 1 and ambient temperature of -40 to +125 °C
- Arduino™ UNO R3 footprint-compatible with expansion “shield” support
- Integrated Open-standard Serial and Debug Adapter (OpenSDA) with support for several industry-standard debug interfaces as well as JTAG connector
- Easy access to the MCU I/O header pins for prototyping
- On-chip connectivity for Ethernet, FlexRay, USB, CAN, LIN, UART/SCI and SPI
- Potentiometer for precise voltage and analog measurement
- 8 user LED
- 2 user push-button switches
- Flexible power supply options
 - micro-B USB
 - 12V External power supply
- Similar hardware across ARM®, S12 and Power Architecture® architecture based MCUs
- DEVKIT-COMM shield boards for extended 4 CAN and 6 LIN ports




- Box includes:
 - DEVKIT-MPC5748G Board
 - USB Cable
- Downloads includes:
 - Quick Start Package
 - S32 Design Studio IDE
 - Application notes


DEVKIT-MPC5748G Board : Overview

The DEVKIT-MPC5748G is an ultra-low-cost development platform for MPC5748G Microcontrollers.

Features include easy access to all MCU I/Os, a standard-based form factor compatible with the Arduino™ pin layout, providing a broad range of expansion board options, and a USB serial port interface for connection to the IDE. The board has option to be powered via USB or an external power supply.



DEVKIT-MPC5748G Board : Pinout



J3

J2

FUNCTION	PORT	PIN
SCL1	PI1	J3-19
SDA1	PI0	J3-17
	NC	J3-15
	GND	J3-13
SCLK_4	PF2	J3-11
SIN_4	PF1	J3-09
SOUT_4	PF0	J3-07
SS_4	PF3	J3-05
Timer	PA2	J3-03
	PA1	J3-01

J3



PIN	PORT	FUNCTION
J3-20	PG9	
J3-18	PG8	
J3-16	PG7	
J3-14	PG6	
J3-12	PI7	
J3-10	PI6	
J3-08	PA15	
J3-06	PA14	
J3-04	PA13	
J3-02	PA12	

FUNCTION	PORT	PIN
	PB15	J2-15
Timer	PB14	J2-13
Timer	PB13	J2-11
	PB12	J2-09
Timer	PB11	J2-07
	PB10	J2-05
LIN4TX(UART)	PA5	J2-03
LIN4RX(UART)	PA6	J2-01

J2




PIN	PORT	FUNCTION
J2-16	PE13	
J2-14	PF15	
J2-12	PE11	
J2-10	PE10	
J2-08	PE9	
J2-06	PE8	
J2-04	PE7	
J2-02	PE6	

Arduino Compatibility
The internal rows of the I/O headers on the DEVKIT-MPC5748G are arranged to fulfill Arduino™ shields compatibility .



DEVKIT-MPC5748G Board : Pinout



J13

J14

7 EXTERNAL USE

Arduino Compatibility
The internal rows of the I/O headers on the DEVKIT-MPC5748G are arranged to fulfill Arduino™ shields compatibility .


J13



FUNCTION	PORT	PIN
	PF11	J13-02
	PF10	J13-04
	PF6	J13-06
	PF4	J13-08
	PF5	J13-10
	PF7	J13-12
	PF8	J13-14
	PF9	J13-16

PIN	PORT	FUNCTION
J13-01	VIN	12V
J13-03	PER_HVA	
J13-05	RESET	MPC5748G Reset
J13-07	3V3_SR	3.3V
J13-9	5V0_SR	5V
J13-11	GND	
J13-13	GND	
J13-15	VIN	12V

J14



FUNCTION	PORT	PIN
	PB4	J14-02
	PB5	J14-04
	PB6	J14-06
	PB7	J14-08
	PD0	J14-10
	PD1	J14-12
	PD2	J14-14
	PD3	J14-16

PIN	PORT	FUNCTION
J14-01	PG13	ADC1_S[1]
J14-03	PG12	ADC1_S[2]
J14-05	PI8	ADC0_S[16]
J14-07	PI11	ADC0_S[19]
J14-9	PI12	ADC0_S[20]
J14-11	PI13	ADC0_S[21]
J14-13	PI14	ADC0_S[22]
J14-15	PI15	ADC0_S[23]



DEVKIT-MPC5748G Board : Pinout



FUNCTION	PORT	PIN
	PF12	J4-19
	PF13	J4-17
	PC6	J4-15
	PC7	J4-13
	PI2	J4-11
	PI3	J4-09
	PH3	J4-07
	PH4	J4-05
	PG3	J4-03
	PG2	J4-01



PIN	PORT	FUNCTION
J4-20	PE5	
J4-18	PE4	
J4-16	PE0	
J4-14	PE1	
J4-12	GND	
J4-10	PER_HVA	
J4-08	PC11	
J4-06	PC10	
J4-04	PG5	
J4-02	PG4	

FUNCTION	PORT	PIN
	PD12	J12-2
	PD10	J12-4
	PD9	J12-6
	PD8	J12-8
	PER_HVA	J12-10
	GND	J12-12
	PD7	J12-14
	PD6	J12-16
	PD5	J12-18
	PD4	J12-20




PIN	PORT	FUNCTION
J12-1	PD15	
J12-3	PD14	
J12-5	PD13	
J12-7	PH8	
J12-9	PH7	
J12-11	PH6	
J12-13	PJ3	
J12-15	PJ2	
J12-17	PJ1	
J12-19	PJ0	

Arduino Compatibility
The internal rows of the I/O headers on the DEVKIT-MPC5748G are arranged to fulfill Arduino™ shields compatibility .




DEVKIT-MPC5748G Board : Jumper Settings



There is only one jumper: J11
It is to select Power source:

- 1-2: **Default** External 12 V Supply
- 2-3: USB powered 5V Supply, through OpenSDA interface



Note: For high power/current consuming applications (like using external shield boards) use “External 12 V Supply” only



DEVKIT-MPC5748G Board : Communication Interfaces

1 of 2

LIN_0


DESCRIPTION	NAME	PIN
	GND	P3-01
	GND	P3-02
Connect to 12V	VBAT	P3-03
Port PB2 & PB3	LIN	P3-04

LIN

CAN_0

DESCRIPTION	NAME	PIN
Port PB0 & PB1	CANH	P5-01
	CANL	P5-02
	NC	P5-03
	GND	P5-04

CAN



FlexRay_A

DESCRIPTION	NAME	PIN
	FRA-DATA-A	P2_1
	FRA-DATA-B	P2_2

FlexRay

FlexRay_A

DESCRIPTION	PORT
FR_A_TX	PC5
FR_A_TX_EN	PE2
FR_A_RX	PE3

Note: LIN Physical Interface require 12V supply on pin P3-03



DEVKIT-MPC5748G Board : Communication Interfaces

2 of 2

UART_2 – LinFlex_2
OpenSDA micro-USB


DESCRIPTION	PORT
TX	PC8
RX	PC9

USB_1

DESCRIPTION	PORT
ULPI1_D7	PH12
ULPI1_D6	PH11
ULPI1_D5	PG11
ULPI1_D4	PG10
ULPI1_D3	PE15
ULPI1_D2	PE14
ULPI1_D1	PG15
ULPI1_D0	PG14
ULPI1_STP	PI4
ULPI1_NXT	PI5
ULPI1_DIR	PC3
ULPI1_CLK	PC2

ETHERNET_0

DESCRIPTION	PORT
RMII_0_TXD[0]	PH1
RMII_0_TXD[1]	PH0
RMII_0_TX_EN	PH2
RMII_0_RXD[0]	PA9
RMII_0_RXD[1]	PA8
RMII_0_RX_ER	PA11
RMII_0_RX_DV	PF15
RMII_0_MDC	PG0
RMII_0_MDIO	PF14
RMII_0_TX_CLK (Reference clock)	PG1




DEVKIT-MPC5748G Board : User Peripherals



DESCRIPTION	PIN	PORT
Potentiometer (ADC0 CH9)	RV1/POT	PB4
User Switch 2	SW2	PE12
User Switch 4	SW4	PA3
User LEDs	DS4	PA10
	DS5	PA7
	DS6	PH13
	DS7	PC4
	DS8	PH5
	DS9	PJ4
	DS10	PA0
	DS11	PA4
Reset Button	SW1	

DEVKIT-MPC5748G Board : Programing Interface



JTAG	
DESCRIPTION	PIN
Support for USB Multilink Interface	P4

OpenSDA Interface	
DESCRIPTION	PIN
OpenSDA MCU Boot Entry	SW3
OpenSDA micro USB: On-board JTAG connection via open source OSBDM circuit using the MC9S08JM60 Microcontroller	J1
OpenSDA JTAG: JTAG to update firmware in OpenSDA MCU	J6

Software Development Tools

- IDE & Compilers

- Free S32 Design Studio IDE for Power Architecture with GCC compiler
- GHS MULTI Integrated Development Environment
- Cosmic IDE
- iSystems winIDEA IDE
- Sourcery™ CodeBench Development Tools



- Debuggers

- Free OpenSDA debugger on board and supported by S32DS IDE
- P&E USB Multilink
- iSystems iC6000
- Lauterbach TRACE32 JTAG Debugger



Pre-Compiled Code Examples

- Pre-compiled example projects are available in S32DS as well as on nxp.com/DEVKIT-MPC5748G for quick start
- Example projects also includes the projects from Application Note, [AN4830: Qorivva Recipes for MPC574xG](#)

List of code examples:

1. Hello
2. Hello+pll
3. Hello+pll+interrupts
4. eDMA+ PBridge
5. Semaphores
6. Register Protection
7. Low Power: STOP mode
8. Analog-to-digital Converter
9. Timed I/O (eMIOS)
10. CAN
11. CAN+DMA
12. LIN
13. UART
14. SPI
15. SPI+DMA
16. I2C
17. Ethernet
18. Body Cross Trigger Unit (BCTU)
19. System Memory Protection Unit (SMPU)
20. Flash



Documentation

General Documents

- [MPC5748G Microcontroller Data Sheet](#)
- [MPC5748G Microcontroller Reference Manual](#)
- [MPC5748G Microcontroller Fact Sheet](#)
- DEVKIT-MPC5748G Board Fact Sheet
- Software Integration Guide (SWIG)

Application Notes

- [AN4830: Qorivva Recipes for MPC574xG](#)
- [AN5220: MPC5748G Hardware Design Guidelines](#)
- [AN5114: Migrating between MPC5748G and MPC5746C](#)
- [AN4868: EEPROM Emulation with NXP MPC55xx, MPC56xx, and MPC57xx Microcontrollers](#)
- [AN4805: A Practical Approach to Hardware Semaphores](#)

MPC574xG/C/B/D Family : Phantom Feature Differences

Flash/RAM	Package			
	100MAPBGA (11x11mm, 1mm)	176LQFP-EP (24x24mm, 0.5mm)	256MAPBGA (17x17mm, 1mm)	324MAPBGA (19x19mm, 1mm)
6M/768k 6M/768k		SPC5748G SPC5748C	SPC5748G SPC5748C	SPC5748G SPC5748C
4M/768k 4M/512k		SPC5747G SPC5747C	SPC5747G SPC5747C	SPC5747G SPC5747C
3M/768k		SPC5746G	SPC5746G	SPC5746G
3M/384k (512k optional) 3M/384k (512k optional)	SPC5746C SPC5746B	SPC5746C SPC5746B	SPC5746C SPC5746B	PPC5746C
2M/256k 2M/256k	SPC5745C SPC5745B	SPC5745C SPC5745B	SPC5745C SPC5745B	
1.5M/192k 1.5M/192k	SPC5744C SPC5744B	SPC5744C SPC5744B	SPC5744C SPC5744B	

Color Coding:

Triple Core, Ethernet, FlexRay, USB, SDHC,
(optional HSM, 2nd Ethernet + switch)

Dual Core, Ethernet, FlexRay
(all: optional HSM, 5747C/5748C: 2nd
Ethernet + switch)

Single Core, FlexRay, Ethernet (optional
HSM)

Debug device for SPC5745B/C and
SPC5746B/C - not for production

- OpenSDA is an open-standard serial and debug adapter
- It bridges serial and debug communications between a USB host and an embedded target processor
- DEVKIT-MPC5748G comes with the OpenSDA Application preinstalled
- Follow these instructions to run the OpenSDA Bootloader and update or change the installed OpenSDA Application

Enter OpenSDA Bootloader Mode

1. Unplug the OpenSDA USB cable if attached
2. Press and hold the Reset button (SW3)
3. Plug in a USB cable between a USB host and the OpenSDA USB connector (labeled “SDA”)
4. Release the Reset button

A removable drive should now be visible in the host file system with a volume label of **BOOTLOADER**. You are now in OpenSDA Bootloader mode.

IMPORTANT NOTE: Follow the “Load an OpenSDA Application” instructions to update the application on your MC9S08JM60 to the latest version. It is likely that the version provided in this package is newer than what was preprogrammed on your MC9S08JM60.

Load an OpenSDA Application

1. While in OpenSDA Bootloader mode, double-click **SDA_INFO.HTML** in the **BOOTLOADER** drive. A web browser will open the OpenSDA homepage containing the name and version of the installed Application. This information can also be read as text directly from **SDA_INFO.HTML**
2. Locate the **OpenSDA Applications** folder
3. Copy & paste or drag & drop the Application *to the* **BOOTLOADER** drive
4. Unplug the USB cable and plug it in again. The new OpenSDA Application should now be running and check the latest version by repeating Step-1

Use the same procedure to load other OpenSDA Applications.




Using the Virtual Serial Port

1. Determine the symbolic name assigned to the DEVKIT-MPC5748G virtual serial port. On Windows platform open Device Manager and look for the COM port named “OpenSDA-CDC Serial Port”.
2. Open the serial terminal emulation program of your choice. Examples for Windows platform include [Tera Term](#), [PuTTY](#), or [HyperTerminal](#).
3. Program one of the “code examples” using S32 Design Studio IDE.
4. Configure the terminal emulation program. Most embedded examples use 8 data bits, no parity bits, and one stop bit (8-N-1). Match the baud rate to the selected serial test application and open the port.
5. Press and release the Reset button (SW1) at anytime to restart the example application. Resetting the embedded application will not affect the connection of the virtual serial port to the terminal program.

NOTE: Refer to the OpenSDA User’s Guide for a description of a known Windows issue when disconnecting a virtual serial port while the COM port is in use.

Recommendations

- For high power/current consuming applications (like using external shield boards) use “External 12 V Supply” only.
- External 12 V Supply Specifications
 - Fully regulated Switching Power Supply
 - Input Voltage: 100-240V AC 50/60Hz
 - Output: 12V 1A/2A DC
 - Plug size: 5.5mm x 2.1 mm, Center Positive 
- By default “New Project” in S32 Design Studio IDE makes application to run at 16 MHz Internal RC (IRC) oscillator. For faster performance, configure PLL to desired frequency and switch clock source to PLL before executing application code.
- For faster debugging, debug from RAM, because this cuts down the lengthy Flash erase operation cycles. Follow the Software Integration Guide (SWIG) for details.
- Keep S32 Design Studio IDE and OpenSDA firmware Up-to-date for best results.
- Post Technical Questions on NXP community for [MPC5xxx](#).
- Useful Links:
 - nxp.com/mpc5748g
 - nxp.com/devkit-mpc5748g
 - nxp.com/s32ds
 - nxp.com/community





SECURE CONNECTIONS
FOR A SMARTER WORLD