SIEMENS

Data sheet

3RA2120-1KD24-0AK6



FUSELESS LOAD FEEDER DIRECT START, AC 400V, SZ. S0, 9...12.5A, AC 110/120V 50/60HZ SCREW TERMINAL FOR BUSBAR SYSTEMS 60MM TYPE OF ASSIGNMENT 2,IQ = 150KA (ALSO FULFILLS TYPE OF ASSIGNMENT 1) 1NO+1NC (CONTACTOR)


product brand name	SIRIUS		
product designation	non-fused load feeders 3RA2		
design of the product	direct starter		
manufacturer's article number			
 of the supplied contactor 	3RT2024-1AK60		
 of the supplied circuit-breakers 	3RV2021-1KA10		
 of the supplied busbar adapter 	8US1251-5NT10		
 of the supplied link module 	<u>3RA2921-1AA00</u>		
General technical data			
size of the circuit-breaker	S0		
size of load feeder	S0		
product extension auxiliary switch	Yes		
insulation voltage with degree of pollution 3 at AC rated value	690 V		
degree of pollution	3		
surge voltage resistance rated value	6 kV		
shock resistance according to IEC 60068-2-27	6g / 11 ms		
mechanical service life (switching cycles) of contactor typical	10 000 000		
type of assignment	2		
Substance Prohibitance (Date)	10/01/2009		
Ambient conditions			
ambient temperature			
 during operation 	-20 +60 °C		
 during storage 	-50 +80 °C		
 during transport 	-50 +80 °C		
Main circuit			
number of poles for main current circuit	3		
design of the switching contact	electromechanical		
adjustable current response value current of the _current-dependent overload release	9 12.5 A		
	9 12.5 A		
current-dependent overload release	9 12.5 A 690 V		
current-dependent overload release operating voltage			
current-dependent overload release operating voltage • rated value • at AC-3 rated value maximum operating frequency rated value	690 V		
current-dependent overload release operating voltage • rated value • at AC-3 rated value maximum	690 V 690 V		
current-dependent overload release operating voltage • rated value • at AC-3 rated value maximum operating frequency rated value	690 V 690 V 50 60 Hz		
current-dependent overload release operating voltage • rated value • at AC-3 rated value maximum operating frequency rated value operational current at AC-3 at 400 V rated value	690 V 690 V 50 60 Hz		
current-dependent overload release operating voltage • rated value • at AC-3 rated value maximum operating frequency rated value operational current at AC-3 at 400 V rated value operating power at AC-3	690 V 690 V 50 60 Hz 11.5 A		


Control circuit/ Control				
control supply voltage at AC				
• at 50 Hz rated value	110 V			
at 60 Hz rated value	120 V			
apparent holding power of magnet coil at AC	8.5 VA			
Protective and monitoring functions				
trip class	CLASS 10			
design of the overload release	thermal (bimetallic)			
response value current of instantaneous short-circuit trip	162.5 A			
unit				
UL/CSA ratings				
full-load current (FLA) for 3-phase AC motor				
at 480 V rated value	11 A			
at 600 V rated value	11 A			
yielded mechanical performance [hp]				
 for single-phase AC motor — at 110/120 V rated value 	0.5 hp			
— at 230 V rated value	0.5 hp 2 hp			
• for 3-phase AC motor	2.10			
- at 200/208 V rated value	3 hp			
— at 220/230 V rated value	3 hp			
— at 460/480 V rated value	7.5 hp			
— at 575/600 V rated value	10 hp			
Short-circuit protection				
product function short circuit protection	Yes			
design of the short-circuit trip	magnetic			
conditional short-circuit current (Iq)				
 at 690 V according to IEC 60947-4-1 rated value 	4 000 A			
 at 400 V according to IEC 60947-4-1 rated value 	153 000 A			
• at 500 V according to IEC 60947-4-1 rated value	42 000 A			
Installation/ mounting/ dimensions				
mounting position	vertical			
mounting position fastening method	for snapping onto 60 mm busbar systems			
mounting position fastening method height	for snapping onto 60 mm busbar systems 260 mm			
mounting position fastening method height width	for snapping onto 60 mm busbar systems 260 mm 45 mm			
mounting position fastening method height width depth	for snapping onto 60 mm busbar systems 260 mm			
mounting position fastening method height width	for snapping onto 60 mm busbar systems 260 mm 45 mm			
mounting position fastening method height width depth required spacing	for snapping onto 60 mm busbar systems 260 mm 45 mm			
mounting position fastening method height width depth required spacing • for grounded parts	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm			
mounting position fastening method height width depth required spacing • for grounded parts — forwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm			
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm			
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm			
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm			
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm			
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm			
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — upwards • for live parts — upwards — upwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 30 mm 30 mm			
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — upwards — downwards — backwards — downwards — backwards — upwards — downwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 10 mm 10 mm 10 mm			
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — upwards — at the side — downwards — at the side — downwards — at the side — upwards — at the side — upwards — at the side	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 30 mm 30 mm			
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — upwards — at the side — downwards — forwards — forwards — at the side — downwards — at the side — ownwards — at the side — ownwards — at the side — downwards — at the side Connections/ Terminals	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 9 mm 10 mm 9 mm 30 mm 9 mm 10 mm 9 mm			
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — downwards • for live parts — forwards — at the side — upwards — backwards — upwards — backwards — upwards — backwards — upwards — downwards — at the side Connections/ Terminals type of electrical connection for main current circuit	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 10 mm 10 mm 10 mm			
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards — backwards — upwards — backwards — upwards — backwards — upwards — other side Connections/ Terminals type of electrical connection for main current circuit type of connectable conductor cross-sections	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 0 mm 30 mm 10 mm 9 mm 10 mm 2 mm 30 mm 10 mm 9 mm 10 mm			
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards — backwards — upwards — downwards — at the side Connections/ Terminals type of electrical connection for main current circuit type of connectable conductor cross-sections • for main contacts stranded	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 9 mm 10 mm 30 mm 30 mm 10 mm 9 mm 10 mm 2 screw-type terminals 1 10 mm ² , 2x (2.5 6 mm ²)			
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — upwards — at the side Connections/ Terminals type of electrical connection for main current circuit type of connectable conductor cross-sections • for main contacts stranded • at AWG cables for main contacts	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 0 mm 30 mm 10 mm 9 mm 10 mm 2 mm 10 mm 10 mm 10 mm 2 mm 10			
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards — backwards — upwards — downwards — at the side Connections/ Terminals type of electrical connection for main current circuit type of connectable conductor cross-sections • for main contacts stranded	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 9 mm 10 mm 30 mm 30 mm 10 mm 9 mm 10 mm 2 screw-type terminals 1 10 mm ² , 2x (2.5 6 mm ²)			
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — ownwards • for live parts — ownwards — upwards — a the side Connections/ Terminals type of electrical connection for main current circuit type of connectable conductor cross-sections • for main contacts stranded • at AWG cables for main contacts connectable conductor cross-section for main contacts	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 0 mm 30 mm 10 mm 9 mm 10 mm 2 mm 10 mm 10 mm 10 mm 2 mm 10 mm 10 mm 10 mm 2 mm 10 m			
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — at the side — downwards • for live parts — forwards — upwards — at the side Ownwards — at the side Connections/ Terminals type of electrical connection for main current circuit type of connectable conductor cross-sections • for main contacts stranded • at AWG cables for main contacts connectable conductor cross-section for main contacts finely stranded with core end processing	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 0 mm 30 mm 10 mm 9 mm 10 mm 2 mm 10 mm 10 mm 10 mm 2 mm 10 mm 10 mm 10 mm 2 mm 10 m			
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — backwards — upwards — backwards — upwards — downwards — at the side Connections/ Terminals type of electrical connection for main current circuit type of connectable conductor cross-sections • for main contacts stranded • at AWG cables for main contacts connectable conductor cross-section for main contacts finely stranded with core end processing Safety related data	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 10 mm 9 mm 10 mm 30 mm 10 mm 9 mm 10 mm 2 mm 10 mm 9 mm 10 mm 10 mm 10 mm 10 mm 10 mm 10 mm 2 mm 10 mm ² , 2x (2.5 6 mm ²) 2x (16 12), 2x (14 8) 1 6 mm ²			

protection class IP on the front according to IEC 60529		IP20				
touch protection on the front according to IEC 60529		finger-safe, for vertical contact from the front				
Certificates/ approva	lls			_	_	
General Product A	pproval			For use in hazard- ous locations	Declaration of Conformity	
	<u>Confirmation</u>	(UL) u	EHC	KEx ATEX	CE EG-Konf.	
Declaration of Conformity	Test Certificates		Marine / Shipping			
UK CA	Special Test Certific- ate	<u>Type Test Cert</u> ates/Test Rep			Lloyds Register urs	
Marine / Shipping				other	Railway	
PRS	RINA		DNV-GL ENVILCEMEN	Confirmation	Vibration and Shock	
Further information Information- and Downloadcenter (Catalogs, Brochures,) https://www.siemens.com/ic10 Industry Mall (Online ordering system) https://mall.industry.siemens.com/mall/en/en/Catalog/product?mlfb=3RA2120-1KD24-0AK6						
Cax online generator http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en&mlfb=3RA2120-1KD24-0AK6 Service&Support (Manuals, Certificates, Characteristics, FAQs,) http://www.pagt.industry.com/ap/ap/2BA2120-1KD24-0AK6						
https://support.industry.siemens.com/cs/ww/en/ps/3RA2120-1KD24-0AK6 Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros,) http://www.automation.siemens.com/bilddb/cax_de.aspx?mlfb=3RA2120-1KD24-0AK6⟨=en Characteristic: Tripping characteristics, I ² t, Let-through current						

https://support.industry.siemens.com/cs/ww/en/ps/3RA2120-1KD24-0AK6/char

Further characteristics (e.g. electrical endurance, switching frequency) http://www.automation.siemens.com/bilddb/index.aspx?view=Search&mlfb=3RA2120-1KD24-0AK6&objecttype=14&gridview=view1





last modified:

12/15/2020 🖸