## Data sheet 3RA2120-1GD24-0BB4



Load feeder fuseless, Direct-on-line starting 400 V AC, Size S0 4.50...6.30 A 24 V DC screw terminal for 60 mm busbar systems (also fulfills type of coordination 1) Type of coordination 2, Iq = 150 kA 1 NO+1 NC (contactor)

product brand name	SIRIUS
product designation	Direct (on-line) starter
design of the product	for 60 mm busbars
product type designation	3RA21
manufacturer's article number	
<ul> <li>of the supplied contactor</li> </ul>	3RT2024-1BB40
<ul> <li>of the supplied circuit-breakers</li> </ul>	3RV2011-1GA10
<ul> <li>of the supplied busbar adapter</li> </ul>	<u>8US1251-5NT10</u>
<ul> <li>of the supplied link module</li> </ul>	3RA2921-1BA00
General technical data	
size of the circuit-breaker	S00
size of load feeder	S0
insulation voltage with degree of pollution 3 at AC rated value	690 V
surge voltage resistance rated value	6 kV
degree of protection NEMA rating	other
shock resistance according to IEC 60068-2-27	6g / 11 ms
mechanical service life (switching cycles) of contactor typical	10 000 000
type of assignment	2
type of protection according to ATEX directive 2014/34/EU	Ex II (2) GD
certificate of suitability according to ATEX directive 2014/34/EU	DMT 02 ATEX F 001
Substance Prohibitance (Date)	10/01/2009
Ambient conditions	
ambient temperature	
<ul> <li>during operation</li> </ul>	-20 +60 °C
<ul> <li>during storage</li> </ul>	-50 +80 °C
during transport	-50 +80 °C
temperature compensation	-20 +60 °C
relative humidity during operation	10 95 %
Main circuit	
number of poles for main current circuit	3
design of the switching contact	electromechanical
adjustable current response value current of the current-dependent overload release	4.5 6.3 A
operating voltage	
rated value	690 V
<ul> <li>at AC-3 rated value maximum</li> </ul>	690 V

operating frequency rated value	50 60 Hz
operational current at AC-3 at 400 V rated value	4.9 A
operating power at AC-3	
at 400 V rated value	2 200 W
Control circuit/ Control	
type of voltage of the control supply voltage	DC
control supply voltage at DC	
rated value	24 V
rated value	24 24 V
holding power of magnet coil at DC	5.9 W
Auxiliary circuit	
product extension auxiliary switch	Yes
Protective and monitoring functions	
trip class	CLASS 10
design of the overload release	thermal (bimetallic)
UL/CSA ratings	
full-load current (FLA) for 3-phase AC motor	
at 480 V rated value	4.8 A
yielded mechanical performance [hp]	
• for 3-phase AC motor	
— at 200/208 V rated value	1 hp
— at 220/230 V rated value	1.5 hp
— at 460/480 V rated value	3 hp
— at 575/600 V rated value	5 hp
Short-circuit protection	
product function short circuit protection	Yes
design of the short-circuit trip	magnetic
conditional short-circuit current (Iq)	
at 400 V according to IEC 60947-4-1 rated value	150 000 A
- at too v according to IEO coot/-T- I lated value	
Installation/ mounting/ dimensions	vertical
Installation/ mounting/ dimensions mounting position	vertical
Installation/ mounting/ dimensions mounting position fastening method	
Installation/ mounting/ dimensions mounting position	vertical for snapping onto 60 mm busbar systems
Installation/ mounting/ dimensions mounting position fastening method height	vertical for snapping onto 60 mm busbar systems 260 mm
Installation/ mounting/ dimensions mounting position fastening method height width	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm
Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  • for grounded parts	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm
Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  • for grounded parts  — forwards	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm
Installation/ mounting/ dimensions  mounting position  fastening method height width depth required spacing • for grounded parts — forwards — backwards	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 20 mm
Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 20 mm
Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 20 mm 10 mm
Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — forwards	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — backwards	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm 10 mm 10 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards - upwards • for live parts — forwards — backwards — upwards	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm 10 mm 10 mm
Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — forwards  — backwards  — upwards  — downwards  — downwards  — downwards  — backwards  — backwards  — backwards  — backwards  — downwards	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm 0 mm 50 mm
Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — forwards  — backwards  — at the side  — downwards  • for live parts  — forwards  — backwards  — backwards  — upwards  — at the side	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm 10 mm 50 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards — for live parts — forwards — backwards — backwards — upwards — at the side Connections/ Terminals	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm 0 mm 50 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards — to a the side — backwards — backwards — backwards — at the side Connections/ Terminals type of electrical connection	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm 10 mm 10 mm 20 mm 20 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — torwards — backwards — torwards — backwards — upwards — torwards — of the side  Connections/ Terminals  type of electrical connection • for main current circuit	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm 10 mm 50 mm 20 mm 10 mm 50 mm 20 mm
Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — forwards  — backwards  — upwards  — backwards  — at the side  Connections/ Terminals  type of electrical connection  • for main current circuit  • for auxiliary and control circuit	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm 10 mm 50 mm 20 mm 10 mm 50 mm 20 mm
Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — forwards  — backwards  — upwards  — at the side  Connections/ Terminals  type of electrical connection  • for main current circuit  • for auxiliary and control circuit  type of connectable conductor cross-sections	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm 10 mm 50 mm 20 mm 10 mm 50 mm 20 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing  • for grounded parts — forwards — backwards — upwards — at the side — downwards  • for live parts — forwards — backwards — upwards — at the side  Connections/ Terminals  type of electrical connection • for auxiliary and control circuit  type of connectable conductor cross-sections • for main contacts	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm 20 mm 10 mm 50 mm
Installation/ mounting/ dimensions mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — a the side Connections/ Terminals  type of electrical connection • for main current circuit • for auxiliary and control circuit  type of connectable conductor cross-sections • for main contacts — stranded • at AWG cables for main contacts connectable conductor cross-section for main contacts	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm 20 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm 50 mm 10 mm 20 mm
Installation/ mounting/ dimensions  mounting position  fastening method  height  width  depth  required spacing  • for grounded parts  — forwards  — backwards  — upwards  — at the side  — downwards  • for live parts  — forwards  — backwards  — upwards  — a the side  Connections/ Terminals  type of electrical connection  • for auxiliary and control circuit  type of connectable conductor cross-sections  • for main contacts  — stranded  • at AWG cables for main contacts	vertical for snapping onto 60 mm busbar systems 260 mm 45 mm 165 mm  20 mm 0 mm 50 mm 10 mm 10 mm 50 mm 10 mm 10 mm 20 mm

B10 value with high demand rate according to SN 31920	1 000 000
proportion of dangerous failures	
<ul> <li>with high demand rate according to SN 31920</li> </ul>	73 %
touch protection on the front according to IEC 60529	finger-safe, for vertical contact from the front
Communication/ Protocol	
protocol is supported	
<ul> <li>PROFINET IO protocol</li> </ul>	No
PROFIsafe protocol	No
protocol is supported AS-Interface protocol	No
Cartificates/approvals	

Certificates/ approvals

**General Product Approval** 

For use in hazardous locations **Declaration of Conformity** 



Confirmation









Declaration of Conformity

**Test Certificates** 

Marine / Shipping



Special Test Certificate Type Test Certificates/Test Report







Marine / Shipping

other Railway









Confirmation

Vibration and Shock

## **Dangerous Good**

<u>Transport Information</u>

## Further information

Information- and Downloadcenter (Catalogs, Brochures,...)

https://www.siemens.com/ic10

Industry Mall (Online ordering system)

https://mall.industry.siemens.com/mall/en/en/Catalog/product?mlfb=3RA2120-1GD24-0BB4

Cax online generator

http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en&mlfb=3RA2120-1GD24-0BB4

Service&Support (Manuals, Certificates, Characteristics, FAQs,...)

https://support.industry.siemens.com/cs/ww/en/ps/3RA2120-1GD24-0BB4

Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros, ...)


http://www.automation.siemens.com/bilddb/cax\_de.aspx?mlfb=3RA2120-1GD24-0BB4&lang=en

Characteristic: Tripping characteristics, I2t, Let-through current

https://support.industry.siemens.com/cs/ww/en/ps/3RA2120-1GD24-0BB4/char

Further characteristics (e.g. electrical endurance, switching frequency)

http://www.automation.siemens.com/bilddb/index.aspx?view=Search&mlfb=3RA2120-1GD24-0BB4&objecttype=14&gridview=view1



last modified: 2/16/2022 🖸