SIEMENS

Data sheet


3RA2120-1GD24-0AK6



FUSELESS LOAD FEEDER DIRECT START, AC 400V, SZ. S0, 4.5...6.3A, AC 110/120V 50/60HZ SCREW TERMINAL FOR BUSBAR SYSTEMS 60MM TYPE OF ASSIGNMENT 2,IQ = 150KA (ALSO FULFILLS TYPE OF ASSIGNMENT 1) 1NO+1NC (CONTACTOR)


product brand name	SIRIUS
product designation	non-fused load feeders 3RA2
design of the product	direct starter
manufacturer's article number	
 of the supplied contactor 	3RT2024-1AK60
 of the supplied circuit-breakers 	3RV2021-1GA10
 of the supplied busbar adapter 	8US1251-5NT10
 of the supplied link module 	3RA2921-1AA00
General technical data	
size of the circuit-breaker	S0
size of load feeder	S0
product extension auxiliary switch	Yes
insulation voltage with degree of pollution 3 at AC rated value	690 V
degree of pollution	3
surge voltage resistance rated value	6 kV
shock resistance according to IEC 60068-2-27	6g / 11 ms
mechanical service life (switching cycles) of contactor typical	10 000 000
type of assignment	2
Substance Prohibitance (Date)	10/01/2009
Ambient conditions	
ambient temperature	
 during operation 	-20 +60 °C
 during storage 	-50 +80 °C
 during transport 	-50 +80 °C
Main circuit	
number of poles for main current circuit	3
design of the switching contact	electromechanical
adjustable current response value current of the current-dependent overload release	4.5 6.3 A
operating voltage	
 rated value 	690 V
 at AC-3 rated value maximum 	690 V
operating frequency rated value	50 60 Hz
operational current at AC-3 at 400 V rated value	5 A
operating power at AC-3	
• at 400 V rated value	2 200 W
• at 500 V rated value	3 000 W
• at 690 V rated value	4 000 W

Control circuit/ Control	
control supply voltage at AC	
at 50 Hz rated value	110 V
at 60 Hz rated value	120 V
apparent holding power of magnet coil at AC	8.5 VA
Protective and monitoring functions	
trip class	CLASS 10
design of the overload release	thermal (bimetallic)
response value current of instantaneous short-circuit trip	81.9 A
unit	
UL/CSA ratings	
full-load current (FLA) for 3-phase AC motor	
at 480 V rated value	4.8 A
at 600 V rated value	6.3 A
yielded mechanical performance [hp]	
 for single-phase AC motor — at 110/120 V rated value 	0.25 hp
— at 230 V rated value	0.25 hp
• for 3-phase AC motor	0.0 Hp
- at 200/208 V rated value	1 hp
— at 220/230 V rated value	1.5 hp
— at 460/480 V rated value	3 hp
— at 575/600 V rated value	5 hp
Short-circuit protection	
product function short circuit protection	Yes
design of the short-circuit trip	magnetic
conditional short-circuit current (Iq)	
 at 690 V according to IEC 60947-4-1 rated value 	4 000 A
 at 400 V according to IEC 60947-4-1 rated value 	153 000 A
 at 500 V according to IEC 60947-4-1 rated value 	100 000 A
Installation/ mounting/ dimensions	
mounting position	vertical
mounting position fastening method	for snapping onto 60 mm busbar systems
mounting position fastening method height	for snapping onto 60 mm busbar systems 260 mm
mounting position fastening method height width	for snapping onto 60 mm busbar systems 260 mm 45 mm
mounting position fastening method height width depth	for snapping onto 60 mm busbar systems 260 mm
mounting position fastening method height width	for snapping onto 60 mm busbar systems 260 mm 45 mm
mounting position fastening method height width depth required spacing	for snapping onto 60 mm busbar systems 260 mm 45 mm
mounting position fastening method height width depth required spacing • for grounded parts	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — upwards • for live parts — upwards — upwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 30 mm 30 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — upwards — downwards — backwards — downwards — upwards — downwards	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 10 mm 10 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — upwards — at the side — downwards — at the side — downwards — at the side — upwards — at the side — upwards — at the side	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 30 mm 30 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — at the side — downwards • for live parts — forwards — upwards — backwards — at the side — ownwards — upwards — upwards — at the side Connections/ Terminals	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 9 mm 10 mm 9 mm 30 mm 9 mm 10 mm 9 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — downwards • for live parts — forwards — at the side — upwards — backwards — upwards — backwards — upwards — backwards — upwards — downwards — at the side Connections/ Terminals type of electrical connection for main current circuit	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 10 mm 10 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards — backwards — upwards — backwards — upwards — backwards — upwards — other side Connections/ Terminals type of electrical connection for main current circuit type of connectable conductor cross-sections	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 0 mm 30 mm 10 mm 9 mm 10 mm 9 mm 10 mm 9 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — downwards • for live parts — forwards — upwards — at the side — downwards — backwards — upwards — at the side Connections/ Terminals type of electrical connection for main current circuit type of connectable conductor cross-sections • for main contacts stranded	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 9 mm 10 mm 30 mm 30 mm 10 mm 9 mm 10 mm 2 screw-type terminals 1 10 mm ² , 2x (2.5 6 mm ²)
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — ownwards — ownwards — at the side — downwards — backwards — upwards — at the side Connections/ Terminals type of electrical connection for main current circuit type of connectable conductor cross-sections • for main contacts stranded • at AWG cables for main contacts	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 0 mm 30 mm 10 mm 9 mm 10 mm 2 mm 10 mm 10 mm 10 mm 2 mm 10
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards — backwards — upwards — downwards — at the side Connections/ Terminals type of electrical connection for main current circuit type of connectable conductor cross-sections • for main contacts stranded	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 9 mm 10 mm 30 mm 30 mm 10 mm 9 mm 10 mm 2 screw-type terminals 1 10 mm ² , 2x (2.5 6 mm ²)
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — ownwards — ownwards — at the side — downwards — backwards — upwards — at the side Connections/ Terminals type of electrical connection for main current circuit type of connectable conductor cross-sections • for main contacts stranded • at AWG cables for main contacts connectable conductor cross-section for main contacts	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 0 mm 30 mm 10 mm 9 mm 10 mm 2 mm 10 mm 10 mm 10 mm 2 mm 10 mm 10 mm 10 mm 2 mm 10 m
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — at the side — downwards • for live parts — forwards — upwards — at the side — downwards — at the side Connections/ Terminals type of electrical connection for main current circuit type of connectable conductor cross-sections • for main contacts stranded • at AWG cables for main contacts connectable conductor cross-section for main contacts finely stranded with core end processing	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 0 mm 30 mm 10 mm 9 mm 10 mm 2 mm 10 mm 10 mm 10 mm 2 mm 10 mm 10 mm 10 mm 2 mm 10 m
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — backwards — upwards — backwards — upwards — downwards — at the side Connections/ Terminals type of electrical connection for main current circuit type of connectable conductor cross-sections • for main contacts stranded • at AWG cables for main contacts connectable conductor cross-section for main contacts finely stranded with core end processing Safety related data	for snapping onto 60 mm busbar systems 260 mm 45 mm 155 mm 10 mm 0 mm 30 mm 9 mm 10 mm 10 mm 10 mm 10 mm 9 mm 10 mm 30 mm 10 mm 9 mm 10 mm 2 mm 10 mm 9 mm 10 mm 10 mm 10 mm 10 mm 10 mm 10 mm 2 mm 10 mm ² , 2x (2.5 6 mm ²) 2x (16 12), 2x (14 8) 1 6 mm ²



Further characteristics (e.g. electrical endurance, switching frequency)

http://www.automation.siemens.com/bilddb/index.aspx?view=Search&mlfb=3RA2120-1GD24-0AK6&objecttype=14&gridview=view1



last modified:

12/15/2020 🖸