

RISH CON-Hz

Frequency transducer

















RISH CON-Hz

Application

The RISH CON - Hz transducer is used for frequency measurement. The output signal is proportional to measured frequency and is either load independent DC Current or load independent DC Voltage.

Salient Features

- Fully onsite programmable input range
- Available in Single or Dual output type
- Onsite selectable output type.(DC current / DC voltage)
- Accuracy class 0.2 (IEC/EN 60688)
- Seven Segment LCD Display
- RS 485(Modbus) Communication
- Wide Auxiliary power supply. Accept any input 60V - 300V AC/DC or 24V - 60V AC/DC
- Output Response Time < 400ms
- Fast and easy installation on DIN RAIL or onto a wall or in a panel using optional screw hole bracket
- Connection Terminal: Conventional Screw type



Fig. 1 RISH CON - Hz

Product Features

Measuring Input

Sine wave or distorted wave form of nominal input voltage with fundamental wave.

Analog Output (Single or dual)

Isolated analog output which can be set onsite to either voltage or current output.

Accuracy

Output signal accuracy Class 0.2 as per International Standard IEC $^{\prime}$ EN 60688.

Programmable Input/Output

The Transducer can be programmed onsite using front key & display or through programming port (COM) or through RS 485.

LED Indication

LED indication for power on and output type.

(Current output: Red LED, Voltage output: Green LED)

Display Module(Optional)

Optional 7 segment LCD display with backlit & keypad. For displaying measured parameters & onsite configuration of Input/output

RS 485 Communication(Optional)

Optional RS485 communication is available. For reading measured parameters & onsite configuration of input/output.

Symbols and their meaning

X Input Frequency

X0 Start value of input

X1 Elbow value of input

X2 End value of input

Y Output DC Voltage / DC Current

Y0 Start value of output DC

Voltage / DC Current

Y1 Elbow value of output DC

Voltage / DC Current

Y2 End value of output DC

Voltage / DC Current

R_N Rated value of output burden

U_N Nominal input voltage



RISH CON-Hz

Technical Specifications

Measuring Input X →

Frequency Transducer (RISH CON - Hz)

Measuring Ranges Nominal input Voltage(UN) Nominal input Voltage burden

Overload Capacity

45Hz to 55Hz, 48Hz to 52Hz, 55Hz to 65Hz, 45Hz to 65Hz (min span 4Hz)

57V ≤ UN ≤ 500 V < 0.6 VA max

1.2 *UN continuously,

2 *UN for 1 second, repeated 10 times at 10 minute intervals (maximum 300V with power supply powered from measuring input).

Measuring Output Y(Single or Optional Dual) (→

Output type

Load independent DC output Output burden with DC current output Signal Output burden with DC voltage output Signal Current limit under overload R=0

Voltage limit under R=∞

Residual Ripple in Output signal

Response Time

Auxiliary Power Supply

AC/DC Auxiliary Supply

AC Auxiliary supply frequency range

Auxiliary supply consumption

Load independent DC Voltage, DC Current onsite selectable through DIP switches

0...20mA / 4...20mA OR 0...10V

 $0 \le R \le 15V/Y2$

 $Y2/(2 \text{ mA}) \leq R \leq \infty$

≤ 1.25 * Y2 with current output ≤ 100 mA with Voltage output < 1.25 * Y2 with voltage output ≤ 30 V with current output

≤ 1% pk-pk < 400 ms

60V... 300 VAC-DC ± 5% or 24V... 60VAC-DC ± 10%

40 to 65 Hz

60V300 VAC-DC	≤ 8VA for Single output			
	≤ 10VA for Dual output			
24V60 VAC-DC	≤ 5 VA for Single output			
	≤ 6 VA for Dual output			









Page No.: 2 www.rishabh.co.in Version No. L 17/12/13

RISH CON-Hz

Accuracy (Acc. to IEC / EN 60688)

Reference Value Output end Value Y2 (Voltage or Current)

Basic Accuracy 0.2*C

Factor C (The highest value applies if calculated C is less than 1,then C=1 applies)

Linear characteristics:

Bent characteristics:

For $X1 \le X \le X2$:

 $C = \frac{1 - \frac{Y0}{Y2}}{1 - \frac{X0}{Y0}}$ or C=1

For $X0 \le X \le X1$:

 $C = \frac{Y1 - Y0}{X1 - X0} \cdot \frac{X2}{Y2}$ or C=1

$$C = \frac{1 - \frac{Y1}{Y2}}{1 - \frac{X1}{X2}} \text{ or } C = 1$$

Reference conditions for Accuracy

Ambient temperature 23°C +/- 1°C

Pre-conditioning 30 min acc. to IEC / EN 60688
Input Variable Rated Voltage / Rated Current
Input waveform Sinusoidal, Form Factor 1.1107

Input signal frequency 50 or 60Hz
Auxiliary supply voltage At nominal range

Output Load $Rn = 7.5 \text{ V / Y2} \pm 1\%$ With DC current output signal $Rn = Y2 / 1 \text{ mA} \pm 1\%$ With DC voltage output signal

Miscellaneous Acc. to IEC / EN 60688

Additional error

Temperature influence ±0.2% /10°C


Influence of Variations


As per IEC / EN 60688 standard Output Stability < 30 min

Output Characteristics

Example of setting with Linear Characteristics:

Example of setting with bent Characteristics:





X0 = Start value of input Y0 = Start value of output X1 = Elbow value of input Y1 = Elbow value of output Y2 = End value of input Y2 = End value of output Y2 = End value (Y2) of output cannot be changed onsite.









RISH CON-Hz

Safety

Protection Class II (Protection Isolated, EN 61010)

Protection IP 40, housing according to EN 60 529

IP 20, terminal according to EN 60 529

Pollution degree

Installation Category Ш

1min. (EN 61010-1) Insulation Voltage

7700V DC, Input versus outer surface 5200V DC, Input versus all other circuits

5200V DC, Auxiliary supply versus outer surface and output

690V DC, Output versus output versus each other versus outer surface.

Installation Data

Mechanical Housing Lexan 940 (polycarbonate)

Flammability Class V-0 acc. to UL 94, self extinguishing,

non dripping, free of halogen

Mounting position Rail mounting / wall mounting

Weight Approx. 0.4kg

Connection Terminal

Connection Element Conventional Screw type terminal with indirect wire pressure

Permissible cross section

of the connection lead \leq 4.0 mm² single wire or 2 x 2.5 mm² fine wire

Environmental

Nominal range of use 0 °C...23 °C...45 °C (Usage Group II)

-40 °C to 70 °C Storage temperature

Relative humidity of annual mean ≤ 75%

Altitude 2000m max

Ambient tests

Vibration EN 60 068-2-6

Acceleration ±2g

Frequency range 10....150...10Hz, rate of frequency sweep: 1 octave/minute

10, in each of the three axes Number of cycles

EN 60 068-2-7 Shock 3*50g Acceleration

3 shocks in each direction

IEC 61000-4-2/-3/-4/-5/-6

EN 55 011 Electromagnetic compatibility










RISH CON-Hz


ON LED	Aux.supply healthy condition	Green LED continuous ON
O/P1 LED	Output1 voltage selection	Green LED continuous ON
OFFILED	Output1 Current selection	Red LED continuous ON
O/DO LED	Output2 voltage selection	Green LED continuous ON
O/P2 LED	Output2 Current selection	Red LED continuous ON


Electrical Connections

Connection	Terminal details			
Measuring input	~ ~	5 6		
Auxilliary Power supply	~ , + ~ , -	7 8		
Measuring output - 1	+ -	1 2		
Measuring output - 2	+ -	3 4		



Dimensions















Page No.: 5 Version No. L 17/12/2020 www.rishabh.co.in

RISH CON-Hz

Programming (Figs. 4 and 5)

Programming of transducer can be done in three ways

- Programming Via Front LCD & two keys
- Programming Via optional RS485(MODBUS) communication port (Device address, Password, communication parameter, Output Type & simulation mode can be programmed)
- Programming Via Programming port available at front of RISH CON Transducers using (optional) PRKAB601 Adapter.


Programming Via Programming port (COM)

A PC with RS 232 C interface along with the programming cable PRKAB601 and the configuration software are required to program the transducer.

The connections between

"PC ← PRKAB 601 ← Rish CON Transducer..

The powersupply mustbe applied to Transducer before it can be programmed.



The Configuration software is supplied on a CD.

The programming cable PRKAB601 adjusts the signal level and provides the electrical insulation between the PC and RISH CON Transducers.

Configuring Rish Con Transducer:

To configure RISH CON Transducer Input / output one of the three programming methods can be adapted along with mechanical switch setting (DIP switch setting on PCB for output).

DIP Switch Setting for OUTPUT:

Type of output (current or voltage signal) has to be set by DIP switch (see Fig.5).

For programming of DIP switch the user needs to open the transducer housing & set the DIP switch located on PCB to the desired output type Voltage or Current.

Output range changing is not possible with DIP switch setting.

Refer below Fig. 5 for DIP switch setting.

The four pole DIP switch is located on the PCB in the RISH CON Transducer

DIP Switch Setting	Type of Output Signal
ON [] [] [] [] [] [] [] [] [] [load-independent current
ON[[]] 1234	load-independent voltage

Fig. 5









Page No.: 6 www.rishabh.co.in Version No. L 17/12/13

RISH CON-Hz

Ordering Information

Product Code	CF41-	Х	XX	X	X	Х	Х	Х	00000
Input Range	45-55Hz	6							
	55-65Hz	В							
	45-65Hz	7							
	48-52Hz	Α							
Input Voltage	100-500V		8F						
Devices Councils	60-300 VAC/DC			Н					
Power Supply	24-60 VAC/DC			F					
Output	1 O/P				1				
Output	2 O/P				2				
Diaplay Madula	With Display					D			
Display Module	Without Display					Z			
RS485 Module	With RS-485						R		
	Without RS-485						Z		
Dragramming Cable	With - PRKAB 601							С	
Programming Cable	Without - PRKAB 601							Z	

Ordering Example - CF41-B8FH1DZZ00000 - 55-65Hz, 100-500V, Aux 60-300 VAC/DC, With display, without RS485, Without - PRKAB 601

Analog DC output options as below, to be specified while ordering only

Current Output	Voltage Output	DIP Option			
Standard Ranges					
0/420 mA	010 V	Yes			
Optional factory set ranges					
010 mA	05 V	No			
05 mA	02.5 V	No			
02.5 mA	01 V	No			
01 mA					

Note: End value of output can not be changed onsite.











RISHABH INSTRUMENTS PVT. LTD.

Domestic (India): +91 253 2202028/99 | marketing@rishabh.co.in International: +91 253 2202004/06/08/99 | global@rishabh.co.in www.rishabh.co.in