SIEMENS

Data sheet

3RA2220-4AB26-0AK6



FUSELESS LOAD FEEDER REVERSING OPERATION, AC 400V, S0 10. . .16A, AC 110/120V 50/60HZ SCREW TERMINAL FOR DIN RAIL MOUNTING, WITH DIN RAIL ADAPTER TYPE OF ASSIGNMENT 2,IQ = 150KA (ALSO TYPE OF ASSIGNMENT 1) 1NO+1NC (CONTACTOR)

product brand name	SIRIUS
product designation	Reversing starter
design of the product	for standard rail or screw mounting
product type designation	3RA22
manufacturer's article number	
 of the supplied contactor 	<u>3RT2026-1AK60</u>
 of the supplied circuit-breakers 	<u>3RV2021-4AA10</u>
 of the supplied RH assembly kit 	<u>3RA2923-1BB1</u>
 of the supplied link module 	<u>3RA2921-1AA00</u>
General technical data	
size of the circuit-breaker	S0
size of load feeder	S0
insulation voltage with degree of pollution 3 at AC rated value	690 V
surge voltage resistance rated value	6 kV
degree of protection NEMA rating	other
shock resistance according to IEC 60068-2-27	6g / 11 ms
mechanical service life (switching cycles) of contactor typical	10 000 000
type of assignment	2
type of protection according to ATEX directive 2014/34/EU	Ex II (2) GD
certificate of suitability according to ATEX directive 2014/34/EU	DMT 02 ATEX F 001
Substance Prohibitance (Date)	05/01/2012
Ambient conditions	
ambient temperature	
 during operation 	-20 +60 °C
 during storage 	-50 +80 °C
during transport	-50 +80 °C
temperature compensation	-20 +60 °C
relative humidity during operation	10 95 %
Main circuit	
number of poles for main current circuit	3
design of the switching contact	electromechanical
adjustable current response value current of the current-dependent overload release	10 16 A
operating voltage	
 rated value 	690 V
• at AC-3 rated value maximum	690 V

operating frequency rated value	50 60 Hz
operational current at AC-3 at 400 V rated value	 15.5 A
	15.5 A
operating power at AC-3 • at 400 V rated value	7 500 W
Control circuit/ Control	7 500 W
	40
type of voltage of the control supply voltage	AC
control supply voltage at AC	440.1/
at 50 Hz rated value	110 V
at 50 Hz rated value	88 121 V
at 60 Hz rated value	120 V
at 60 Hz rated value	96 132 V
apparent holding power of magnet coil at AC	9.8 VA
Auxiliary circuit	
product extension auxiliary switch	Yes
Protective and monitoring functions	
trip class	CLASS 10
design of the overload release	thermal (bimetallic)
UL/CSA ratings	
full-load current (FLA) for 3-phase AC motor	
at 480 V rated value	14 A
yielded mechanical performance [hp]	
 for 3-phase AC motor 	
— at 220/230 V rated value	5 hp
— at 460/480 V rated value	10 hp
— at 575/600 V rated value	10 hp
Short-circuit protection	
product function short circuit protection	Yes
design of the short-circuit trip	magnetic
conditional short-circuit current (Iq)	
 at 400 V according to IEC 60947-4-1 rated value 	150 000 A
Installation/ mounting/ dimensions	
mounting position	vertical
	On adapter for screw and snap-on mounting on 35 mm standard
mounting position fastening method	On adapter for screw and snap-on mounting on 35 mm standard mounting rail
mounting position fastening method height	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm
mounting position fastening method height width	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm
mounting position fastening method height width depth	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm
mounting position fastening method height width depth required spacing	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm
mounting position fastening method height width depth	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm
mounting position fastening method height width depth required spacing • for grounded parts	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm 0 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm 0 mm 50 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm 0 mm 50 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm 0 mm 50 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm 0 mm 50 mm 10 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards • for live parts — backwards	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — upwards • for live parts — forwards — upwards • for live parts — upwards — upwards	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 50 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — downwards • for live parts — downwards — backwards — backwards — upwards — downwards	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 50 mm 10 mm 50 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — upwards — at the side — downwards — a the side — upwards — a the side — upwards — at the side	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 50 mm 10 mm 50 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — at the side — downwards • for live parts — forwards — upwards — at the side — downwards — at the side — upwards — at the side — connections/ Terminals	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 50 mm 10 mm 50 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — at the side — downwards — backwards — at the side — upwards — backwards — at the side Connections/ Terminals type of electrical connection	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm 0 mm 50 mm 10 mm 32 mm 0 mm 10 mm 10 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards — backwards — upwards — backwards — upwards — backwards — upwards — ownwards — othe side Connections/ Terminals type of electrical connection • for main current circuit	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 10 mm 50 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — a the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 10 mm 50 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards - at the side — downwards • for live parts — forwards — upwards — backwards — upwards — for norwards — for ive parts — forwards — upwards — at the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit Safety related data	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 10 mm 50 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — upwards — at the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit Safety related data B10 value with high demand rate according to SN 31920	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 10 mm 50 mm 10 mm
mounting position fastening method height width depth required spacing • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards — backwards — upwards — at the side Connections/ Terminals type of electrical connection • for main current circuit • for auxiliary and control circuit Safety related data B10 value with high demand rate according to SN 31920 proportion of dangerous failures	On adapter for screw and snap-on mounting on 35 mm standard mounting rail 265 mm 90 mm 120 mm 32 mm 0 mm 50 mm 10 mm 10 mm 32 mm 0 mm 50 mm 10 mm 10 mm 10 mm 10 mm 10 mm 10 mm 10 mm 10 mm

Communication/ Prot	ocol					
 protocol is supporte PROFINET IO PROFIsafe pro 	protocol	No				
protocol is supported	AS-Interface protocol	No				
Certificates/ approval	ls					
General Product Ap	oproval			For use in hazard- ous locations	Declaration of Conformity	
(SP)	<u>Confirmation</u>		EHC	KEX ATEX	CE EG-Konf.	
Declaration of Conformity	Test Certificates		Marine / Shipping			
UK CA	<u>Type Test Certific-</u> ates/Test Report	<u>Special Test Certific-</u> <u>ate</u>	ABS	B U R E AU VERITAS	Llovd's Register us	
Marine / Shipping				other	Railway	
PRS	RINA	KMRS RARS	DIVISION DI	<u>Confirmation</u>	Vibration and Shock	
iurther information Information- and Downloadcenter (Catalogs, Brochures,) https://www.siemens.com/ic10 Industry Mall (Online ordering system) https://mall.industry.siemens.com/mall/en/en/Catalog/product?mlfb=3RA2220-4AB26-0AK6						

https://mall.industry.siemens.com/mall/en/en/Catalog/product?mlfb=3RA2220-4AB26-0AK6

Cax online generator

http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en&mlfb=3RA2220-4AB26-0AK6

Service&Support (Manuals, Certificates, Characteristics, FAQs,...)

https://support.industry.siemens.com/cs/ww/en/ps/3RA2220-4AB26-0AK6

Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros, ...)

http://www.automation.siemens.com/bilddb/cax_de.aspx?mlfb=3RA2220-4AB26-0AK6&lang=en

Characteristic: Tripping characteristics, I²t, Let-through current

https://support.industry.siemens.com/cs/ww/en/ps/3RA2220-4AB26-0AK6/char

Further characteristics (e.g. electrical endurance, switching frequency)

 $\label{eq:http://www.automation.siemens.com/bilddb/index.aspx?view=Search\&mlfb=3RA2220-4AB26-0AK6\&objecttype=14\&gridview=view1$

last modified:

3/9/2022 🖸